

Gigaset

E490-E495

Issued by
Gigaset Communications GmbH
Schlavenhorst 66, D-46395 Bocholt
Gigaset Communications GmbH is a trademark licensee of Siemens AG


© Gigaset Communications GmbH 2008
All rights reserved.
Subject to availability. Rights of modifications reserved.

www.gigaset.com



SIEMENS

The handset at a glance



- 3 **Display keys** (→ page 17)
- 4 **Message key**
Access to calls and message lists;
Flashes: new message or new call
- 5 **End call key, On/Off key**
End call, cancel function, go back one menu level (press briefly), back to idle status (press and hold), activate/deactivate handset (press and hold in idle status)
- 6 **Hash key**
Keypad lock on/off (press and hold in idle status);
swaps between upper/lower case and digits
- 7 **Call-by-call list key**
Open call-by-call list
- 8 **Connection socket** for headset
(→ page 14)
- 9 **Microphone**
- 10 **Recall key**
- Consultation call (flash)
- Insert a dialling pause (press and hold)
- 11 **Star key**
Ringer on/off (press and hold),
With an open connection: switch between dial pulsing/tone dialling (press briefly);
Text input: Open table of special characters
- 12 **Key 1**
Dial answering machine (E495 only)/
network mailbox (press and hold)
- 13 **Talk key**
Answer a call, open last number redial list (press briefly), start dialling (press and hold)
When writing an SMS: send SMS
- 14 **Speaker key**
Switch between earpiece and speaker mode;
Lights up: speaker activated;
Flashes: incoming call
- 15 **Control key** (→ page 16)
- 16 **Eco Mode** enabled (→ page 45)
- 17 **Answering machine symbol** (E495 only)
Answering machine switched on;
Flashes: Answering machine is recording a message or is being operated by another internal party
- 18 **Eco Mode+** enabled (→ page 45)

- 1 **Display** in idle status
- 2 **Charge status of the batteries**
 - (flat to full)
 - flashes: batteries almost flat
 - flashes: batteries charging



Gigaset service contact numbers:

For personal advice on our range of products and for repairs or guarantee/warranty claims call:

Service Centre UK: 08453 6708 12
(local call cost charge)

Please have your proof of purchase ready when calling.

The base station at a glance

The base station at a glance



Registration/Paging key (→ page 47)

Contents

The handset at a glance	1
The base station at a glance	2
Safety precautions	6
First steps	7
Check the pack contents	7
Installing the base station and charging cradle	8
Connecting the base station	8
Connecting the charging cradle	9
Setting up the handset for use	10
Connecting the headset	14
What would you like to do next?	15
Using the phone	16
Control key	16
Display keys	17
Keys on the keypad	17
Correcting incorrect entries	17
Menu guidance	17
Activating/deactivating the handset	18
Activating/deactivating the keypad lock	18
Illustration in the user guide	19
Menu tree	20
Making calls	22
Making an external call	22
Ending a call	22
Answering a call	22
Calling Line Identification	22
Speaker	23
Switch to on hold	23
Making calls using network services	24
Calling Line Identification	24
Ringback	24
Call waiting during an external call	24
Call divert (CD)	25
Consultation call, call swap	25
Using the directory and lists	26
Directory/call-by-call list	26
Last number redial list	28
Opening lists with the message key	28

Making cost-effective calls	30
Linking call-by-call numbers with one number	30
Automatic network provider code (preselection)	30
SMS (text messages)	31
Writing/sending an SMS	31
Receiving an SMS	32
Notification by SMS	34
SMS mailboxes	34
Setting SMS centres	35
SMS on a PABX	36
Activating/deactivating first ringer muting	36
Activating/deactivating SMS function	36
SMS troubleshooting	37
Operating the answering machine of the Gigaset E495 base station	38
Operation via the handset	38
Activating/deactivating call screening	41
Setting up the answering machine	42
Resetting fast access for the answering machine using key 1	42
Operating when on the move (remote operation)	43
Using the network mailbox	44
Configuring fast access for the network mailbox	44
Viewing the network mailbox message	44
ECO DECT	45
Setting the alarm clock	46
Using several handsets	46
Registering handsets	46
De-registering handsets	47
Locating a handset ("paging")	47
Making internal calls	47
Listening in to an external call	48
Changing the name of a handset	49
Changing a handset's internal number	49
Using a handset as a room monitor	49

Handset settings	51
Quick access to functions	51
Changing the display language	51
Setting the display	51
Setting the screen picture	52
Setting the display lighting	52
Activating/deactivating auto answer	52
Changing the speaker/earpiece volume	52
Changing ringers	53
Activating/deactivating advisory tones	54
Restoring the handset default settings	54
Base station settings	54
Protecting against unauthorised access	54
Activating/deactivating music on hold	55
Repeater support	55
Restoring the base station to the factory settings	55
Connecting the base station to the PABX	56
Dialling modes and recall	56
Saving an access code (outside line code)	56
Setting pauses	57
Switching temporarily to tone dialling (DTMF)	57
Service (Customer Care)	58
Questions and answers	58
Authorisation	59
Guarantee Certificate	59
United Kingdom	59
Environment	60
Appendix	61
Care	61
Contact with liquid	61
Specifications	62
Writing and editing text	63
Accessories	64
Mounting the base station to the wall	66
Mounting the charging cradle to the wall	66
Index	67

Safety precautions

Warning

Read the safety precautions and the user guide before use.
Explain their content and the potential hazards associated with using the telephone to your children.



Only use the mains adapter supplied, as indicated on the underside of the base station or charging cradle.



Only use the **recommended, rechargeable batteries** (→ page 62), i.e. never use a conventional (non-rechargeable) battery or other battery types as this could result in significant health risks and personal injury.



The operation of medical appliances may be affected. Be aware of the technical conditions in your particular environment, e.g. doctor's surgery.



Do not hold the rear of the handset to your ear when it is ringing or when the speaker function is activated. Otherwise you risk serious and permanent damage to your hearing.

The handset may cause an unpleasant humming noise in hearing aids.



Do not install the base station or charging cradle in bathrooms or shower rooms. The base station and charging cradle are not splashproof (→ page 61).



Do not use your phone in environments with a potential explosion hazard (e.g. paint shops).



If you give your Gigaset to someone else, make sure you also give them the user guide.



Please remove faulty base stations from use or have them repaired by our Service department, as they could interfere with other wireless services.

Please note

Not all of the functions described in this user guide are available in all countries.

First steps

Check the pack contents



- 1 one Gigaset E490/E495 base station
- 2 one mains adapter for the base station
- 3 one Gigaset E49H handset
- 4 one charging cradle
- 5 one mains adapter for the charging cradle
- 6 two batteries
- 7 one battery cover
- 8 one belt clip
- 9 one lock ring
- 10 one phone cord
- 11 one rubber headset socket cover
- 12 one user guide

Installing the base station and charging cradle

The base station and charging cradle are designed for use in enclosed dry rooms with a temperature range of +5°C to +45°C.

- ▶ Place the base station in a central location in your flat or house. Position the base station and charging cradle on a level, non-slip surface or mount them on the wall → page 66.

Please note

- ◆ Pay attention to the range of the base station. This is up to 300 m in unobstructed outdoor areas and up to 50 m inside buildings.
- ◆ The range is reduced when eco mode is on (→ page 45).


The phone's feet do not usually leave any marks on surfaces. However, due to the multitude of different varnishes and polishes used on today's furnishings, the occurrence of marks on the surfaces cannot be completely ruled out.

Please note:

- ◆ Never expose the telephone to the influence of heat sources, direct sunlight or other electrical devices.
- ◆ Protect your Gigaset from moisture, dust, corrosive liquids and vapours.

Connecting the base station


- ▶ **First** connect the mains adapter **1**.
- ▶ **Then** connect the telephone jack **2** and insert the cables into the cable ducts.



Please note:


- ◆ The mains adapter must **always be connected**, as the phone will not operate without mains connection.
- ◆ Only use the mains adapter and phone cord **supplied**. Pin connections on telephone cables can vary (pin connections → page 62).

Connecting the charging cradle



- ▶ Connect the flat plug of the mains adapter **1**.
- ▶ Plug the mains adapter into the plug socket **2**.

If you need to disconnect the plug from the charging cradle, press the release button **1** and disconnect the plug **2**.



Setting up the handset for use

The display and control key are protected by a plastic film.
Please remove the protective film!

Inserting the batteries and closing the battery cover

Warning

Only use the rechargeable batteries recommended by Gigaset Communications GmbH * (→ page 62), i. e. never use conventional (non-rechargeable) batteries, as this could result in significant health risks and personal injury. For example, the outer casing of the batteries could be damaged or the batteries could explode. The phone could also malfunction or be damaged as a result of using batteries that are not of the recommended type.

* Gigaset Communications GmbH is a licensee of the Siemens trademark.



- ▶ Insert the batteries the right way round. The polarity is indicated in/on the battery compartment.




- ▶ Hold the battery cover at a slight angle and insert the bottom into the casing first **(a)**.
- ▶ Then press the cover **(b)** until it clicks into place.



- ▶ Insert the lock ring or belt clip into the battery cover as shown (at an angle of approx. 20°). Pay attention to the arrow markings on the lock ring.
- ▶ Turn the lock ring or belt clip clockwise to the end stop. The lock ring is closed once the markings on the ring are aligned with those on the cover.




- ▶ Insert the rubber headset socket cover provided to guarantee the unit is splashproof.



If you need to reopen the battery cover, for instance to change the batteries, please proceed as follows:

- ▶ Turn the lock ring or belt clip anti-clockwise to the end stop (approx. 20°) and remove. Position your thumb and index finger on both sides of the lock ring.
- ▶ Insert a suitable tool (e.g. a small coin) into the cavity at the top of the battery cover and twist it until the cover opens.



Placing the handset in the charging cradle

- ▶ Insert the mains adapter of the charging cradle into the mains socket.
- ▶ Place the handset in the charging cradle with its **display facing forward**.

The handset is registered with the base station at the factory. You do not need to complete a registration. If you wish to use your handset with a different base station or use further handsets with your base station, you will have to register the handset manually → page 46.


To charge the battery, leave the handset in the charging cradle.

Please note

Only place the handset in the charging cradle that is intended for it.

First battery charge and discharge

The correct charge status can only be displayed if the battery is first fully charged **and** discharged.



Please note


- ◆ After the first battery charge **and** discharge, you may place your handset in the charging cradle after every call.
- ◆ Always repeat the charging and discharging procedure if you remove the battery from the handset and reinsert it.
- ◆ The battery may heat up during charging. This is not dangerous.
- ◆ After a time, the charge capacity of the battery will decrease for technical reasons.

Setting the date and time

Set the date and time so that the correct date and time can be assigned to incoming calls, and so that the alarm can be used.




- ▶ If you have not yet set the date and time, press the key below **Time** to open the input field.



- ▶ The active line is marked [...]. Enter day, month and year as a 6-digit number via the keypad, e.g. for 01/10/2009.



- ▶ Press down on the control key to enter the time.




- ▶ Enter the hours and minutes in 4-digit format via the keypad, e.g. for 07:15 am.



- ▶ Press the key below **Save** on the display screen to confirm your setting.

Display in idle status

Once the phone is registered and the time set, the idle display is shown as in this example. If the answering machine is activated, the answering machine icon  will also be displayed in the header.

Displays

 Eco Mode+ activated (→ page 45)


 Eco Mode activated (→ page 45)

Charge status of the batteries:

   (flat to full)

 flashes: batteries almost flat

INT 1 Internal name of the handset
(→ page 49)




If **Eco Mode+** (→ page 45) is **not** activated, the top left of the display shows the quality of the radio contact between the base station and handset:

- ◆ Good to poor:     
- ◆ No reception:  flashes

Your answering machine is set with a pre-recorded announcement.

Your phone is now ready for use!

Connecting the headset



After removing the rubber cover, you can connect a headset to the underside of your telephone with the 2.5 mm jack connector. HAMA and Plantronics M40, MX100 and MX150 headsets are all suitable.

After using the headset, always replace the rubber cover.

A compatibility list of tested headsets can be found on the Internet at: www.plantronics.com/productfinder.

What would you like to do next?

Now you have successfully started your Gigaset, you will probably want to adapt it to your personal requirements. Use the following guide to quickly locate the most important subjects.

If you are unfamiliar with menu-driven devices such as other Gigaset telephones you should first read the section entitled "Using the phone"
→ page 16.

Information on ...


... is located here.

Eco Mode / Eco Mode+	→ page 45
Setting the ringer and volume	→ page 53
Setting the earpiece volume	→ page 52
Recording your own announcement for the answering machine	→ page 38
Preparing the telephone for SMS reception	→ page 31
Operating the telephone on a PABX	→ page 56
Registering existing Gigaset handsets to a base station	→ page 46
Transferring directory entries from existing Gigaset handsets to the new handset(s)	→ page 27

If you have any queries about using your phone, please read the tips on troubleshooting ("Questions and Answers" → page 58) or contact our customer service department (Customer Care → page 58).

Using the phone





Control key

In the description below, the side of the control key (up, down, right, left) that you have to press in the different operating situations is marked in black, e.g.  for "press on the right of the control key".






The control key has a number of different functions:







When the handset is in idle status

-  Open the directory.
-  Open the main menu.
-  Open the list of handsets.
-  Call up the menu for setting the handset's call volume (→ page 52), ringers (→ page 53) and advisory tones (→ page 54).




In the main menu, in submenus and lists

-  /  Scroll up/down line by line.
-  /  Open the submenu or confirm the selection.
-  Go back one menu level or cancel.

In input fields


You can use the control key to move the cursor up , down , right  or left .

During an external call

-  Open the directory.
-  Initiate internal consultation call and mute.
-  Adjust the loudspeaker volume for earpiece and speaker mode.

Display keys

The function of the display keys changes depending on the particular operating situation. Example:



- 1 Current display key functions are shown in the bottom display line.
- 2 Display keys

The most important display keys are:

- Options** Open a context-dependent menu.
- <C** Delete key: backspace deletes one character at a time.
- ↶** Go back one menu level or cancel operation.
- Copy number into directory.
- ☎** Divert external call to answering machine (E495 only).
- Open the last number redial list.

Keys on the keypad

 /  /  etc.

Press the matching key on the handset.

 Enter digits or letters.

Correcting incorrect entries

You can correct incorrect characters in the text by navigating to the incorrect entry using the control key. You can then:

- ◆ Press **<C** to delete the character to the left of the cursor
- ◆ Insert characters at the cursor position
- ◆ Overwrite the (flashing) character when entering the time and date etc.

Menu guidance

Your telephone's functions are accessed using a menu that has a number of levels.

Main menu (first menu level)

- ▶ Press  with the handset in idle status to open the main menu.

The main menu functions are shown in the display as a list with colour icons and names.

To access a function, i.e. to open the corresponding submenu (next menu level):

- ▶ Navigate to the function using the control key . Press the display key **OK**.

Submenus

The functions in the submenus are displayed as lists.

To access a function:

- ▶ Scroll to the function with the control key  and press **OK**.


Or:

- ▶ Enter the corresponding digit combination (➔ page 20).

Briefly press the end call key  once to return to the previous menu level/cancel the operation.

Reverting to idle status

You can revert to idle status from anywhere in the menu as follows:

- ▶ Press and **hold** the end call key .

Or:

- ▶ Do not press any key: after 2 minutes the display will **automatically** revert to idle status.

Changes that you have not confirmed or saved by pressing **OK**, **Yes**, **Save**, **Send** or **Save Entry** **OK** will be lost.

An example of the display in idle status is shown on page 14.

Activating/deactivating the handset



With the phone in idle status, press and **hold** the end call key (confirmation tone) to switch off the handset.

Press and **hold** the end call key again to switch the handset on.

Activating/deactivating the keypad lock

The keypad lock prevents any inadvertent use of the phone.



Press and **hold** the hash key in idle status to activate or deactivate the keypad lock. You will hear the confirmation tone.

When the keypad lock is activated you will see the  icon on the display and a message when you press a key.

The keypad lock is deactivated automatically if someone calls you. It is reactivated when the call is finished.

Illustration in the user guide

The operating steps are shown in abbreviated form.

Example

The illustration:



means:




- ▶ To display the main menu, press the right side of the control key in idle status.



- ▶ Press the bottom of the control key until Settings is highlighted by the bar.



- ▶ Press the display key **OK** to open the submenu.



- ▶ **Date/Time** is already indicated.
- ▶ Press the display key **OK** to open the function menu.
- ▶ To enter the time and date, proceed as described on page 13.

Menu tree

Instead of scrolling to locate a menu function, you can select a function more quickly by opening the menu and keying in a digit combination (or shortcut).

Example:      for "Set ringer for external calls".

With the telephone in **idle status**, press  (open main menu):

1 SMS 

You have activated an SMS mailbox (general or private) without a PIN

1-1	New SMS	→	page 31
1-2	Incoming 0	→	page 33
1-3	Outgoing 0	→	page 31

You have activated an SMS mailbox with a PIN or 2-3 mailboxes

1-1	Mailbox	→	1-1-1	New SMS	→	page 31
			1-1-2	Incoming 0	→	page 33
			1-1-3	Outgoing 0	→	page 31
1-2	Mailbox 1 to Mailbox 2 1-4 Mailbox 3		1-2-1	New SMS	→	page 31
			1-4-1			
			1-2-2	Incoming 0	→	page 33
			1-4-2			
			1-2-3	Outgoing 0	→	page 31
			1-4-3			
1-6	Settings		1-6-1	Service Centres	→	page 35
			1-6-2	SMS Mailboxes	→	page 34
			1-6-3	Notify Number	→	page 34
			1-6-4	Notify Type	→	page 34

2 Sel. Services 

2-3	Writhold No.	→	page 24			
2-6	All Calls		2-6-1	Call Diversion	→	page 25
			2-6-3	Call Waiting	→	page 24
2-7	Ringback Off	→	page 24			

3 Alarm Clock  → page 46



4 Add. Features 

4-3	Room Monitor	→	page 49
-----	--------------	---	---------




Making calls

Making an external call

External calls are calls using the public telephone network.

  Enter the number and press the talk key.

Or:

  Press and **hold** the talk key  and then enter the number.


You can cancel the dialling operation with the end call key .

You are shown the duration of the call while the call is in progress.


Please note

Dialling using the directory, the call-by-call list (→ page 1/ → page 26) or the calls and last number redial list (→ page 29/ → page 28) saves you from having to re-enter numbers and network provider prefixes ("call-by-call numbers").




Ending a call

 Press the end call key.

Answering a call

The handset indicates an incoming call in three ways: by ringing, by a display on the screen and by the flashing speaker key .

You can accept the call by:

- ▶ Pressing the talk key .
- ▶ Pressing the speaker key .
- ▶ Gigaset E490: Press the display key **Accept**.
- ▶ Gigaset E495: Press the display key  to divert the call to the answering machine (→ page 41).

If the handset is in the charging cradle and the Auto Answer function is activated (→ page 52), the handset will take a call automatically when you lift it out of the cradle.

To deactivate the ringer, press the **Silence** display key. You can take the call as long as it is displayed on the screen.


Calling Line Identification

When you receive a call, the caller's number is displayed on the screen if the following conditions are met:


- ◆ Your network provider supports CLIP, CLI.
 - CLI (Calling Line Identification): the caller's number is transmitted.
 - CLIP (Calling Line Identification Presentation): the caller's number is displayed.
- ◆ You have arranged CLIP with your network provider.
- ◆ The caller has requested CLI from the network provider.

Call display with CLIP/CLI

If the caller's number is saved in your directory, the caller's name will also be displayed.



or



- 1 Ringer icon
- 2 Number or name of caller

The following is displayed in place of the number:

- ◆ External, if no number is transmitted.
- ◆ Withheld, if the caller has withheld Calling Line Identification (→ page 24).
- ◆ Unavailable, if the caller has not arranged Calling Line Identification.

Speaker

In speaker mode, instead of holding the handset to your ear you can put it down, for example on the table in front of you. This allows others to participate in the call.


Activating/deactivating speaker

Activating while dialling

  Enter the number and press the speaker key.



- ▶ You should inform your caller before you use the speaker function so that they know someone else is listening.

Switching between earpiece and speaker mode

 Press the speaker key.

During a call and when listening to the answering machine (Gigaset E495 only), activate or deactivate speaker.

If you wish to place the handset in the charging cradle during a call:

- ▶ Press and hold the speaker key  while placing the handset in the base station. If speaker key  does not light up, press the key again.

For instructions on how to adjust the loudspeaker volume → page 52.

Switch to on hold

You can deactivate the microphone in your handset during an external call. The other party hears hold music.

 Press left on the control key to mute the handset.

 Press the display key to switch the microphone back on.

You can turn the hold music on and off (→ page 55).

Making calls using network services

Network services are functions that your network provider makes available to you. You have to request these services from your network provider.

► **If you require assistance, please contact your network provider.**

Calling Line Identification

Withhold Calling Line Identification once (CLIR):

If you make a call, your number is shown in the display of the call recipient if that person has activated CLIP (→ page 22).

If in certain instances you do not wish to have your number displayed, you can withhold your number for the next call (CLIR).



Withhold No.



Enter phone number.



Press the talk key.

Ringback

Initiating ringback

If the number you have called is engaged, you can initiate ringback. As soon as the line of the person you called is free, your handset will ring.

You hear the busy tone.



Options → Ringback



Press the end call key.

Cancelling ringback

You can cancel a ringback that has already started.



Ringback Off

Call waiting during an external call

If the function is activated during an **external** call, you will hear a call waiting tone to signal that another external caller is trying to get through. If you have CLIP, (→ page 22) the number of the waiting caller or the corresponding directory entry is shown in the display.

Activating/deactivating call waiting



All Calls → Call Waiting

Status:

Activate/deactivate.



Send Press the display key.

Accepting a waiting call

You are making an external call and hear the call waiting tone.

You have the following options:



Options → Accept waiting call

or

(only if the phone number or name of the caller is displayed)



Accept Press the display key.

Once you have accepted the waiting call you can switch between the two callers ("call swap" → page 25).



Enter the second participant's telephone number.

The phone number is dialled. You are connected to the second participant.

If the caller does not answer, select the display key **End** to return to the first participant.

Please note

You can also select the second participant's phone number from the directory (➔ page 28) or the calls list (➔ page 29).

Call divert (CD)

When diverting a call, the call is forwarded to another connection.

The following options are available:

- ◆ **All Calls:** Calls are diverted immediately. No more calls are signalled on your phone.
- ◆ **No Answer:** Calls are diverted if no one accepts the call within several rings.
- ◆ **When Busy:** Calls are diverted when your line is busy. Call is diverted without a call waiting tone.

➔ ➔ All Calls ➔ Call Diversion

▶ Change multiple line input:

When:

Select All Calls / No Answer / When Busy.

Phone #:

Press the display key **Edit**. Enter the number to which the call is to be diverted

Or:

Press . Select number from the directory and press **OK**.

Status:

Activate/deactivate call divert.



Press the display key.

After the announcement, press the end call key.

Consultation call, call swap

These functions enable you to

- ◆ Call a second external caller (external call)
- ◆ Switch between two calls (call swap)

External call

You can call a second external caller.

The first call is placed on hold.

During an external call:



Press the display key.

The previous call is placed on hold. The other participant hears an announcement.



Enter the second participant's telephone number.

The phone number is dialled. You are connected to the second participant.

If the caller does not answer, select the display key **End** to return to the first participant.

Please note

You can also select the second participant's phone number from the directory (➔ page 28) or the calls list (➔ page 29).

Ending a consultation call

Options ➔ End Active Call

You are reconnected to the first caller.

Call swap

You can speak to both callers one at a time (call swap).

Precondition: You are conducting an external call and have called a second participant (external call) or have accepted a waiting call.

▶ Use to swap between the participants.

The caller you are currently speaking to is marked with the ▶ icon.

End the current call

Options ➔ End Active Call

You are re-connected to the waiting caller.

Using the directory and lists

The options are:

- ◆ Directory
- ◆ Call-by-call list
- ◆ Last number redial list
- ◆ SMS list
- ◆ Calls list
- ◆ Answering machine list (Gigaset E495 only)

You create the directory and call-by-call list for your own individual handset. You can also send lists/entries to other handsets (→ page 27).

Directory/call-by-call list

You can save a total of 150 entries in the directory and call-by-call list.

Please note

For quick access to a number from the directory (Shortcut), you can assign the number to a key.

In the **directory** you can save numbers and corresponding names.

- ▶ With the handset in idle status, open the directory by pressing the  key.

In the **call-by-call list**, you can save network provider prefixes ("call-by-call numbers").

- ▶ Open the call-by-call list in idle status by pressing the  key.

Length of the entries

Number: max. 32 digits

Name: max. 16 characters

Storing a number in the directory

 → New Entry

- ▶ Change multiple line input:

Number

Enter the number.

Name

Enter name.

Speed Dial

Select key for shortcut.

- ▶ Save the changes.

Storing a number in the call-by-call list

 → New Entry

- ▶ Change multiple line input:

Number

Enter the number.

Name

Enter name.



Order of directory entries

The directory entries are usually sorted in alphabetical order. Spaces and digits take first priority. The sort order is as follows:



1. Space
2. Digits (0–9)
3. Letters (alphabetical)
4. Other characters

To work round the alphabetical order of the entries, insert a space or a digit in front of the name. These entries will then move to the beginning of the directory.





Selecting entries in the directory and call-by-call list

 /  Open the directory or call-by-call list.

You have the following options:

- ◆ Use  to scroll through the entries until the required name is selected.
- ◆ Enter the first character of the name and scroll to the entry using  if required.

Dialling with the directory/call-by-call list

-  /  →  (select entry).
-  Press the talk key. The number is dialled.

Managing directory/call-by-call entries

-  /  →  (select entry).



Viewing entries

- View** Press the display key. The entry is displayed. Back with **OK**.

Editing entries

- View** **Edit** Press display keys one after the other.
- ▶ Carry out changes and save.

Using other functions

- Options** Press the display key. The following functions can be selected with :
- Display Number** To edit or add to a saved number, or to save it as a new entry, press  after the number is displayed.

Edit Entry

Edit selected entry.

Delete Entry

Delete selected entry.

VIP Entry (directory only)

Mark a directory entry as a **VIP** (Very Important Person) and assign a specific ringer to it. You can then recognise important calls from the ringer.

Precondition: Calling Line Identification (→ page 22).

Copy Entry

Send a single entry to a handset (→ page 27).

Delete List

Delete **all** entries in the directory/call-by-call list.

Copy List

Send complete list to a handset (→ page 27).

Available Memory

Display the available entries in the directory and call-by-call list (→ page 26).

Using shortcut keys

- ▶ Press and **hold** the required shortcut key (→ page 26).

Sending the directory/call-by-call list to another handset

Preconditions:

- ◆ The sending and receiving handsets must both be registered to the same base station.
- ◆ The other handset and the base station can send and receive directory entries.

 /  →  (select entry) → **Options** (open menu) → Copy Entry / Copy List

Select the internal number of the receiving handset and press **OK**.

You can transfer several individual entries one after the other by responding **Yes** to the Copy next entry? prompt.

A successful transfer is confirmed by a message and confirmation tone on the receiving handset.

Please note:

- ◆ Entries with identical numbers are not overwritten on the receiving handset.
- ◆ The transfer is cancelled if the phone rings or if the memory of the receiving handset is full.

Copying a displayed number to the directory

Numbers displayed in a list, e.g. the calls list or the last number redial list, in an SMS or during a call can be copied to the directory.

A number is displayed:




Options → **Copy to Directory**


▶ Complete the entry, → page 26.

Gigaset E495: The message playback is interrupted during the number transfer from the answering machine list.

Copying a number from the directory

There are many operating situations in which you can open the directory, e.g. to copy a number. Your handset need not be in idle status.


▶ Depending on the operating situation, open the directory with  or  or  Directory.

 Select entry (→ page 26).


Last number redial list

The last number redial list contains the twenty numbers last dialled with the handset (max. 32 digits). If a number is in the directory or the call-by-call list, then the appropriate name will be displayed.

Manual last number redial

 Press the key **briefly**.


 Select entry.

 Press the talk key again.

The number is dialled.

When a name is displayed, you can display the corresponding phone number by pressing the display key **View**.

Managing entries in the last number redial list

 Press the key **briefly**.

 Select entry.

Options Open menu.

The following functions can be selected with :

Display Number (as in the directory, page 27)

Copy to Directory

Copy an entry to the directory (page 26).

Delete Entry (as in the directory, page 27)

Delete List (as in the directory, page 27)


Opening lists with the message key




You can use the message key  to open the following list selection:

◆ SMS list
If **several** mailboxes are set up (→ page 34), several lists are displayed.

◆ Answering machine list (Gigaset E495 only) or Network mailbox, if your network provider supports this function and the fast access is set for the (→ page 44) network mailbox.


◆ Calls list


An advisory tone sounds as soon as a **new message** arrives in a list. The  key flashes (it goes off when the key is pressed). In **idle status**, the display shows an icon for the new message:

Icon	New message...
	... in the answering machine list (Gigaset E495 only) or on the network mailbox
	... in the calls list
	... in the SMS list

The number of new entries is shown beneath the corresponding icon.

List selection

If you press the message key , only the lists that contain messages are shown (exception: network mailbox). Lists with new messages are identified in bold:



Select a list with . To open, press  or **OK**.

If only one list contains entries, no list selection is offered and the relevant list is displayed immediately.

Incoming SMS message list

All received SMS messages are saved in the incoming message list, page 32.

Calls list

Precondition: Calling Line Identification (CLIP, page 22)

Depending on the type of list set, the calls list contains

- ◆ Accepted calls ()
- ◆ Missed calls
- ◆ Calls recorded by the answering machine (∞, Gigaset E495 only)

Depending on the type of list set, all numbers of the last 30 incoming calls are saved or just the missed calls are saved.

Setting the calls list type

 →  → Base → Calls List Type

Missed Calls / All Calls

Select and press **OK** ( = on).

 Press and **hold** (idle status).


The calls list entries are retained when you change the list type.

List entry

New messages are displayed at the top.

Example of list entries:



- ◆ List type (in header)
- ◆ Status of entry
 - Bold:** New entry
- ◆ Number or name of caller
 - You can add the caller's number to the directory (→ page 28).
- ◆ Date and time of call (if set, page 13)
- ◆ Type of entry:
 - Accepted calls ()
 - Missed calls
 - Calls recorded by the answering machine (∞, Gigaset E495 only)

Pressing the display key **Delete** deletes the highlighted entry.

After pressing the display key **Options** you can select more functions with :

- Copy to Directory**
 - Copying a displayed number to the directory.
- Delete List**
 - Delete complete list.

When you quit the calls list, all entries are set to the status "old", i.e. the next time you call the list up they will no longer be shown in bold.

Answering machine list (Gigaset E495 only)

You can use the **answering machine list** to listen to the messages that are on the answering machine.

Making cost-effective calls

Make phone calls through a network provider who offers particularly low-cost call rates (call-by-call). You can manage the numbers in the call-by-call list.

Linking call-by-call numbers with one number

You can insert the dialling code of a network provider ahead of the number ("linking").



Open call-by-call list.



Select entry (call-by-call number).



Press the display key.

Display Number

Select and press **OK**.



Enter number or select number from the directory (→ page 28).



Press the talk key. Both numbers are dialled.

Automatic network provider code (preselection)

You can store a call-by-call number (preselection number), which is **automatically** placed in front of numbers when you dial them.

In the "**With Preselect**" list, specify the dialling codes or the first digits of the dialling codes with which you wish the preselection number to be used.

In the "**Without Presel.**" list enter the exception to the "**With Preselect**" list.

Example:

Preselect no.	0999
With Preselect	08
Without Presel.	081 084

All numbers that start with 08 except for 081 and 084 are dialled with the preselection number 0999.

Phone number	Dialled number
07112345678	→ 07112345678
08912345678	→ 0999 08912345678
08412345678	→ 08412345678

Saving preselection numbers



→ Base → Preselection

→ Preselect No.



Enter or change the preselection number (call-by-call number).



Press the display key.



Press and hold (idle status).

Save or change entries in the preselection lists

Each of the two lists can contain 20 entries, each with 6 digits.

Numbers may be prefixed according to the country in the "**with preselection**" list. This means, for example, that all national calls or calls to the mobile network are **automatically** linked to the preselection number you have saved previously.



→ Base → Preselection

→ With Preselect / Without Presel.



Select entry.



Press the display key.



Enter or edit first digits of number.



Press the display key.



Press and hold (idle status).

Temporarily cancelling preselection



(press and hold) → Options

→ Aut Preselect off

Permanently deactivating preselection

- ▶ Delete the preselection number (→ page 30).

SMS (text messages)

Your phone is supplied ready for sending SMS messages immediately.

Preconditions:

- ◆ Calling Line Identification is enabled for your phone line.
- ◆ Your network provider supports SMS on the fixed line network (information on this can be obtained from your network provider).
- ◆ You are registered with your service provider to send and receive SMS.
- ◆ To have reception you must be registered with your service provider. This is completed automatically when you send your first SMS.

Please note

If your phone is connected to a PABX, please read page 36.

Sending an SMS

 Press the talk key

Or:

Options Press the display key.

Send Select and press **OK**.

SMS Select and press **OK**.



Select number with area code (even if you are in that area) from the directory or call-by-call list, or enter number

directly. For sending SMS to an SMS mailbox: add the mailbox ID to the **end** of the number.

Send Press the display key. The SMS is sent.

Please note

If you are interrupted by an external call while writing an SMS, the text is automatically saved in the draft message list.

Writing/sending an SMS

Writing an SMS



Mailbox 2 Select mailbox if necessary and press **OK**.



Enter mailbox PIN if necessary and press **OK**.



New SMS Select and press **OK**. Write an SMS.

Please note

- ◆ Instructions on entering text can be found on page 63.
- ◆ An SMS can be up to 612 characters. If there are more than 160 characters, the SMS is sent as a **linked** SMS (up to 4 SMS messages with 153 characters each).

Draft message list

You can save an SMS in the draft message list, and edit and send it later.

Saving an SMS in the draft message list

▶ Writing an SMS (→ page 31).

Options Press the display key.

Save Entry Select and press **OK**.

Opening the draft message list

→ → or (mailbox, mailbox PIN) → **Outgoing**


The first list entry is displayed, e.g.

1234567890
15.01.09 09:45

SMS (text messages)

Reading or deleting SMS messages

- ▶ Open the draft message list and then:
 -  Select SMS.

Read Press the display key. The entry will be displayed. Scroll line by line using .

Or delete the SMS with

Options → **Delete Entry** → **OK**.

Writing/changing an SMS

- ▶ You are reading an SMS in the draft message list.

Options Open menu.

You have the following options:

New SMS

Write a new SMS and then send (→ page 31) or save it.

Edit

Edit the text of the saved SMS and then send it (→ page 31).

Character Set

Text is shown in the selected character set.

Deleting draft message list

- ▶ Open the draft message list and then:

Options Open menu.

Delete all Select, press **OK** and confirm with **Yes**. The list is cleared.

 Press and **hold** (idle status).

Receiving an SMS

All received SMS messages are saved in the incoming message list. Linked SMS messages are displayed as **one** message. If this is too long or is not transferred completely, it is split into individual messages. Since an SMS remains in the list even after it has been read, you should **regularly delete SMS messages from the list**.

The display tells you if the SMS memory is full.



Please note

Each incoming SMS is signalled by a single ring (ringer as for external calls). If you accept such a "call", the SMS will be lost. To prevent this ring, suppress the first ringer for all external calls (→ page 36).

Incoming message list

The incoming message list contains:

- ◆ All received SMS messages, starting with the most recent.
- ◆ SMS messages that could not be sent due to an error.

New SMS messages are signalled on all Gigaset E49H handsets by the  icon in the display, the flashing message key  and an advisory tone.

Opening the incoming message list with the key

 Press.

The incoming message list is indicated by the mailbox name and the number of entries (example):

SMS:

- 1 **Bold:** number of new entries
- 2 **Regular:** number of read entries

If necessary select a mailbox and open list by selecting **OK** (if necessary enter mailbox PIN and confirm by pressing **OK**).

The number and date of receipt are displayed in the entry list.

1234567890	
15.01.09	09:45

Opening the incoming message list via the SMS menu

 →  → or Select mailbox, enter mailbox PIN → Incoming

Deleting the incoming message list

All **new and old** SMS messages in the list are deleted.

▶ Open the incoming message list.


Options Open menu.

▶ To continue, see "Deleting draft message list", page 32.

Reading or deleting SMS messages

▶ Open the incoming message list, then:

 Select SMS.

Read Press the display key. The entry will be displayed. Scroll line by line using .

Or delete the SMS with

Options → Delete Entry → **OK**.

After you have read a new SMS, it is given the status "Old" (is no longer shown in bold).

Changing the character set

▶ Reading an SMS

Options Press the display key.

Character Set

Text is shown in the selected character set.

Replying to or forwarding text messages

▶ Reading an SMS

Options Press the display key.

You have the following options:

Reply

Write and send a reply SMS directly (→ page 31).

Edit

Edit the text in the SMS and then send it (→ page 31).

Forward

Forward the SMS to another number (→ page 31).

Copying the number to the directory

Copying the sender's number

▶ Open the incoming message list and select entry (→ page 32).

Options → Copy to Directory


▶ Complete the entry → page 28.

Please note An attached mailbox identifier is added to the directory.

Copying/dialling numbers from an SMS text


▶ Read the SMS and scroll to the telephone number.

The digits are highlighted.

 Press the display key.

Complete the entry → page 28.

Or:

 Press the talk key to dial the number.

If you wish to use the number to send an SMS:

▶ Save the number with the local area code (dialling code) in the directory.

Notification by SMS

You can be notified about missed calls or new answering machine messages (Gigaset E495 only) via SMS.

Precondition: For missed calls, the caller's number (CLI) must have been transmitted.

Notification is sent to your mobile phone or another phone with SMS functionality.

You only need to save the phone number to which notification should be sent (notification number) and set the notification type.

Saving the notification number



→ → Settings → Notify Number

Enter the number to which the SMS should be sent.

Save Press the display key.

Please note

Do **not** enter your own fixed line network number for the notification of missed calls. This can lead to chargeable endless looping.

Setting the notification type



→ → Settings → Notify Type

▶ Change multiple line input if necessary:

Missed Calls

Select On if you require SMS notification.

Ans Machine (Gigaset E495 only)

Select On if you require SMS notification.

▶ Save the changes.

SMS mailboxes

The **general mailbox** is the default setting. Anyone can access this mailbox and it cannot be protected by a PIN. You can additionally set up three **personal mailboxes** and protect these with a **PIN**. Each mailbox is identified by a name and a "mailbox ID" (a kind of extension number).

Please note:

- ◆ If you operate a number of devices (base stations) with SMS functionality on a single phone line, then each SMS mailbox ID may only occur once. In this case you must also change the preset ID of the general mailbox ("0").
- ◆ You can only use personal mailboxes if your service provider supports this function. You can tell whether this is the case by the addition of a star (*) to the number of a (preset) SMS centre.
- ◆ If you have forgotten your mailbox PIN, you can reset it by restoring the base station's default settings. This will **delete all SMS messages from all mailboxes**.

Setting up and changing a personal mailbox

Setting up a personal mailbox



→ → Settings → SMS Mailboxes



Select mailbox, e.g. Mailbox 2 and press **OK**.

▶ Change multiple line input:

On/Off

Activate or deactivate mailbox.

ID

Select mailbox ID (0–9). You can only select the available numbers.



Protection

Activate/deactivate PIN protection.

PIN

If necessary, enter 4-digit PIN.

▶ Save the changes.

Active mailboxes are marked with  in the mailbox list. They are shown in the SMS list and can, if necessary, be displayed by pressing the message key .

Deactivating a mailbox

- ▶ Set **On/Off** to **Off**. Confirm message with **Yes** if necessary.

All SMS messages saved in this mailbox will be deleted.

Deactivating PIN protection


- ▶ Set **Protection** to **Off**.

The mailbox PIN is reset to "0000".

Changing the name of a mailbox

-  →  → **Settings** → **SMS Mailboxes** →  (Select mailbox)

Edit Press the display key.

 Enter new name.

Save Press the display key.

 Press and **hold** (idle status).

Changing a mailbox's PIN and ID

-  →  → **Settings** → **SMS Mailboxes** →  (Select mailbox)

 Enter mailbox PIN if necessary and press **OK**.

- ▶ Set **ID**, **Protection** and **PIN** (→ page 34).

Sending an SMS to a personal mailbox

To send an SMS to a personal mailbox, the sender must know your ID and enter it after your number.

- ▶ You can send your SMS contact an SMS via your personal mailbox.

Your SMS contact will receive your SMS number with current ID and can save it in their directory. If the ID is invalid, the SMS will not be delivered.

Setting SMS centres

SMS messages are exchanged between SMS centres operated by service providers. You must enter the SMS centre through which you wish to send and receive SMS messages into your phone.

You can receive SMS messages from **every** SMS centre that is entered, provided you have registered with your service provider.

Your SMS messages are sent through the SMS centre that is entered as the active send service centre (→ page 35). Only one SMS centre can be the active send service centre at any one time.

If no SMS service centre is entered, the SMS menu only contains the entry **Settings**. Enter an SMS Service Centre (→ page 35).

Entering/changing SMS centres

- ▶ You should find out about the services and special functions offered by your service provider **before you make a new application** and/or before you delete pre-configured call numbers.

 →  → **Settings** → **Service Centres**

 Select SMS centre (e.g. Service Centr. 1) and press **OK**.

- ▶ Change multiple line input:

Active send

Select **Yes** if SMS messages are to be sent via the SMS centre.

SMS

Press the display key **Edit**. Enter the number of the SMS service and insert a star if your service provider supports personal mailboxes.

Save Press the display key.

Please note

Ask your service provider for details on how to enter service numbers if you wish to use personal mailboxes (precondition: your service provider supports this function).

SMS (text messages)







Sending an SMS via another SMS centre


- ▶ Activate the SMS centre (2 to 4) as the active send service centre.
- ▶ Send the SMS.

SMS on a PABX

- ◆ You can only receive an SMS when the **Calling Line Identification is forwarded** to the extension of the PABX (CLIP). The CLIP evaluation of the phone number for the SMS centre takes place in your **Gigaset**.
 - ◆ Depending on your PABX, you may have to add the access code (external line prefix) before the number of the SMS centre.
If in doubt, test your PABX, e.g. by sending an SMS to your own number: once with and once without the access code.
 - ◆ When you send SMS messages, your sender number may be sent without your extension number. In this case the recipient cannot reply to you directly.
- Sending and receiving SMS messages **on ISDN PABXs** is only possible via the MSN number assigned to your base station.

Activating/deactivating first ringer muting

 Open menu.
    
Press keys.

 Make the first ring audible.

Or:

  Mute the first ring.

Activating/deactivating SMS function

If you deactivate the SMS function, you cannot send or receive any SMS messages with your phone.

The settings you have made for sending and receiving SMS messages (e.g. the numbers of the SMS centres) and the entries in the incoming and draft message lists are saved even after deactivation.

 Open menu.

    
Enter the digits.

 Deactivate SMS function.

Or:

  Activate SMS function (default setting).

SMS troubleshooting

Error codes when sending

E0	Calling Line Identification permanently withheld (CLIR) or Calling Line Identification not activated.
FE	Error occurred during SMS transfer.
FD	Connection to SMS centre failed; see self-help.

Self-help with errors

The following table lists error situations and possible causes and provides notes on troubleshooting.

SMS function is not available.	<p>The memory is full or the SMS function on the base station is being used by another handset.</p> <ul style="list-style-type: none"> ▶ Delete SMS messages you no longer require or send the SMS later. <p>You cannot send messages.</p> <ol style="list-style-type: none"> 1. You have not requested the CLIP service (Calling Line Identification Presentation). <ul style="list-style-type: none"> ▶ Ask your service provider to enable this service. 2. SMS transmission has been interrupted (e.g. by a call). <ul style="list-style-type: none"> ▶ Re-send the SMS. 3. The network provider does not support this feature. 4. No number or an invalid number is entered for the SMS centre set as the active send service centre. <ul style="list-style-type: none"> ▶ Enter the number (➔ page 35). <p>You receive an incomplete SMS.</p> <ol style="list-style-type: none"> 1. Your phone's memory is full. <ul style="list-style-type: none"> ▶ Delete old SMS messages (➔ page 33). 2. The service provider has not yet sent the rest of the SMS.
--------------------------------	---

You have stopped receiving SMS messages.

1. You have changed the ID of your mailbox.
 - ▶ Give your SMS contacts your new ID or undo the change (➔ page 35).
2. You have not activated your mailbox.
 - ▶ Activate your mailbox (➔ page 35).
3. Call divert is activated with All Calls or call divert for All Calls is activated for the network mailbox.
 - ▶ Change the call divert.

The SMS is played back.

1. The "display call number" service is not activated.
 - ▶ Ask your service provider to activate this function (chargeable).
2. Your mobile phone operator and your fixed line network SMS service provider have not agreed on a co-operation.
 - ▶ Obtain information from your fixed line network SMS service provider.
3. Your terminal has been recorded by your SMS provider as having no fixed line network SMS functionality, i.e. you are no longer registered with the provider.
 - ▶ Have the device (re-)registered to receive SMS messages.

Messages are only received during the day.

The terminal is recorded in your SMS provider's database as having no fixed line network SMS functionality, i.e. you are not registered with the provider.

- ▶ Obtain information from your fixed line network SMS service provider.
- ▶ Have the device (re-)registered to receive SMS messages.

Operating the answering machine of the

Gigaset E495 base station


You can operate the answering machine that is integrated in the base station via the handset or via remote operation (other phone/mobile phone). You can only record your own announcement messages using the handset.

Announcement mode

You can use the answering machine in two different modes.


- ◆ In **Ans. & Record** mode, the caller hears the announcement and can then leave a message.
- ◆ In **Announce Only** mode, the caller hears your announcement but cannot leave a message.

Operation via the handset

The handset loudspeaker activates **automatically** if you receive an acoustic prompt or message while operating. You can switch it off with the speaker key .

Activating/deactivating the answering machine

 →  → **Voice Mail** → **Ans Machine**
( = on)

When you switch the answering machine on, the remaining memory time is announced. If the time has not yet been set (→ page 13), an appropriate announcement is made. The  icon appears in the display.

The phone is supplied with pre-recorded announcements for answer and record mode and for answer only mode. If a personal announcement has not been recorded, the relevant pre-recorded announcement is used.

Recording announcement/announce only

 →  → **Voice Mail** → **Announcements**
→ **Record Announce / Record Anc Only**

OK Press the display key to start the recording.

You hear the ready tone (short tone).

- ▶ Now speak your announcement (at least 3 secs.).

End Press the display key to end the recording.

Cancel the recording with  or . Restart the recording with **OK**.

After recording, the announcement is played back for you to check. You can re-record the announcement with **New**.

Please note:

- ◆ Recording ends automatically if the maximum recording time of 3 minutes is exceeded or there is a break in speech for more than 2 seconds.
- ◆ If you cancel the recording, the pre-recorded announcement will be used again.
- ◆ If the answering machine's memory is full, it will switch to **Announce Only** mode.
 - ▶ Delete old messages and the answering machine will automatically switch back to **Ans. & Record** mode. Repeat recording if required.

Playing back announcements

 →  → Voice Mail → Announcements
→ Play Announce / Play Anc Only

If you have not recorded a personal announcement, the relevant pre-recorded announcement is played.

Record a new announcement while playing back the announcement:

New Press the display key.

- ◆ If the answering machine's memory is full, it will switch to **Announce Only** mode.
 - ▶ Delete old messages and the answering machine will automatically switch back to **Ans. & Record** mode. Repeat recording if required.

Deleting announcements/announce only

 →  → Voice Mail
→ Announcements → Del Announce /
Del Anc Only

Yes Press the display key to confirm the prompt.

 Press and **hold** (idle status).

Once you have deleted your announcement, the relevant pre-recorded announcement will be used again.

Selecting announcement mode

You can choose between **Ans. & Record** and **Announce Only**.

 →  → Voice Mail
→ Announcements → Set Ans. Mode
→ Ans. & Record / Announce Only ( = on)
 Press and **hold** (idle status).

The selected mode is saved even after the answering machine is deactivated.

If the memory for messages is full in **Ans. & Record** mode, the answering machine will switch to the **Announce Only** mode and you will receive an instruction to delete old messages.

- ▶ Delete old messages.

The answering machine **automatically** switches back to the set mode once deletion is complete. You can then reselect the required recording mode.

Setting "Ans Mode Time" in "Answer & Record" or "Announce Only" mode

You can use the **Ans Mode Time** setting to change over the announcement mode for a specific period.

Example: **Ans. & Record** mode is set. If you activate **Ans Mode Time** and set a period (e.g. 18:00 to 08:00) the answering machine switches to **Announce Only** mode for this period. Outside this period (08:01 to 17:59), **Ans. & Record** mode is active.

 →  → Voice Mail → Announcements
→ Set Ans. Mode → Ans Mode Time
( = on)

- ▶ Change multiple line input:

From

Enter hours/minutes for the start of the period in 4-digit format.

Until

Enter hours/minutes for the end of the period in 4-digit format.

Activation

Select **On** or **Off**.

- ▶ Save changes with **Save**.

If the messages memory is full and **Activation On** has been selected, saving is interrupted and you will receive an instruction to delete old messages.


- ▶ Delete old messages and repeat the setting.


As soon as you change the announcement mode (▶ page 39), the **Ans Mode Time** function is automatically deactivated.

Playing back messages

The date and time of each message is logged (provided this has been set, page 13) and displayed during the playback. If Calling Line Identification is activated, the caller's number is displayed. If the caller's number is saved in the directory, their name is displayed.

Playing back new messages

New messages that have not yet been heard are indicated by the  icon in the display and by the  key flashing on the handset.

 Press the message key.

Ans M. Select and press **OK**.

An announcement informs you if there are new or old messages.

If there are new messages, playback then begins with the first new message. After the last new message you will hear the end tone and an announcement about how much recording time remains.

If the message has been saved with the date and time, you will hear an appropriate announcement before playback begins.

Playing back old messages

You can listen to old message if there are no more new messages. Begin playback as described under "Playing back new messages".

After the entry time and date have been played back (after approx. 3 seconds) a new message assumes the status "old".

Stopping and controlling playback

During message playback:

 Pause playback. Press  again to resume.

 or 

Return to the start of the current message.
Press twice to go back to the previous message.

 or 

Skip to the next message.
Press twice to skip to the next but one message.

If playback is interrupted for over a minute, the answering machine returns to idle status.

Marking a message as "new"

A previously played back "old" message is displayed as a "new" message again.

During message playback:

 Press the star key.

An announcement informs you of the message's new status.

Or:

Options Open menu.

Mark as New

Select and press **OK**.

Playback of the current message is cancelled. Playback of next message starts, if applicable.

The  key on the handset flashes.

Copying the phone number of a message to the directory

See "Copying a displayed number to the directory", page 28.

Deleting messages

You can either delete all old messages together or individually.

Deleting all old messages

During playback or pause:

Options Press the display key.

Del All Old Msgs

Select and press **OK**.

Yes Press the display key to confirm the prompt.

Deleting individual old messages

During playback or pause:

Delete Press the display key.


Picking up a call from the answering machine

You can pick up a call while the answering machine is recording or is being operated via remote operation:



Press the talk or display key.

Recording stops and you can speak to the caller.

If 2 seconds of the call have already been recorded when you pick it up, the call will be displayed as a new message. The  key on the handset flashes.

You can answer the call even if it is not signalled on the handset.

Diverting an external call to the answering machine


You can divert an incoming external call to the answering machine even if it is deactivated.

Precondition: Sufficient memory space is available on the answering machine.

An external call is signalled on the handset:



Press the display key.

The answering machine immediately starts in recording mode and records the call. The set time for ring delay ( \rightarrow page 42) is ignored.

Activating/deactivating two-way record


You can record an **external** call with the answering machine.

 Inform the caller that the call is being recorded.



Open menu.

Two-way Record

Select and press .

Two-way record is indicated on the display by an advisory text and is added to the answering machine list as a new message.



Press the display key to stop two-way record.

The maximum recording time depends on the memory available on the answering machine. If the memory is full you will hear an end tone, the recording is aborted, and the call recorded up to that point is listed in the answering machine list as a new message. If the answering machine was in Ans. & Record mode, it will switch to **Announce Only** mode. You will receive an instruction to delete old messages.

 Delete old messages.

The answering machine **automatically** switches back to the set mode once deletion is complete.

Activating/deactivating call screening

During recording of a message you can screen a call via the loudspeaker of registered handsets.

Permanently activating/deactivating call screening

 \rightarrow  \rightarrow Voice Mail \rightarrow Call Screening \rightarrow Handset ( = on)



Press and **hold** (idle status).

You can switch off the Call Screening function on the handset during the recording.

Deactivating call screening for the current recording



Press the display key.

Setting up the answering machine

The answering machine has already been preset at the factory. Make individual settings using the handset.

Ring delay/cost saving function for remote operation

You can set when you want the answering machine to accept a call.

The options are: **No delay**, after 10 sec., 18 sec. or 30 sec. and the cost-saving setting **Automatic**.


In **Automatic** mode, the following applies for ring delay:

- ◆ If there are no new messages, the answering machine answers a call after 18 seconds.
- ◆ If new messages are present, the answering machine accepts a call after **10 seconds**.

When operating remotely you can tell after approx. 15 seconds that there are no new messages (otherwise the answering machine would already have accepted your call). There will be no call charges if you hang up now.

 →  → **Voice Mail** → **Ring Delay**

Select **No delay** / 10 sec. / 18 sec. / 30 sec. / **Automatic**.

 **Save** Press the display key.

Press and **hold** (idle status).

Please note:


You can configure your telephone so that the **first ring is suppressed** on all calls (→ page 36). The time set for ring delay therefore does not indicate how long the phone rings before the answering machine accepts the call.

Setting the recording time

You can set the maximum recording time of a message. The options are: 1, 2, 3 mins or **Maximum**.

 →  → **Voice Mail** → **Message Length**

Select the recording time.


 **Save** Press the display key.

Setting the recording quality

Set the quality you require for your recordings. The options are: **Long Play**, **High**, **Excellent**. If the quality is higher, the maximum recording time is reduced.

 →  → **Voice Mail** → **Recording Quality**

Select the recording quality.

 **Save** Press the display key.

Resetting fast access for the answering machine using key 1


The integrated answering machine has already been preset for fast access at the factory. However, if you have set the network mailbox for fast access (→ page 44), you can reset this setting.

 →  → **Voice Mail** → **Set Key 1**

Answer Machine / Network Mailb.

Select and press **OK**.

 **Save** Press and **hold** (idle status).

After you have selected the network mailbox or the answering machine, press and **hold** key . You will be connected directly.

The setting for fast access applies to all Gigaset E49H handsets.

Operating when on the move (remote operation)

You can check and activate your answering machine from any other telephone (hotel, pay phone etc.), or initiate ring-back from the answering machine with an SMS.

Preconditions:

- ◆ You have set a system PIN other than 0000 (→ page 55).
- ◆ The phone you are using for remote operation has tone dialling (DTMF), i.e. you hear different tones when you press the keys. Alternatively, you can use a code transmitter (available from your mobile phone retailer).

Calling the answering machine and playing back messages



Dial your own number.
When you hear your announcement, press **9** and enter the system PIN.

You will be informed whether any new messages have been recorded. The messages are now played back. You can now operate the answering machine with the keypad.

The following keys are used for operation:

- 1** To return to the start of the current message.
Press twice to go back to the previous message.
- 2** Stop playback. Press again to resume.
- 3** Go to the next message.
- *** Mark message as "new".
- 0** Delete current message.

Activating the answering machine

- ▶ Phone home and let the phone ring until you hear: "Please enter PIN".



Enter system PIN.

Your answering machine is activated. It tells you how much memory time is left. The messages are now played back.

The answering machine cannot be deactivated remotely.

Initiating ringback from the answering machine with SMS and listening to messages

Precondition: You must have stored a notification number (→ page 34).

You can use the telephone (mobile phone or any other device with SMS functionality) for which you have stored the notification number in your phone to send an SMS to your answering machine when you are away from home. It will then call you back. The message playback begins after the ring delay when you press any key.

The SMS must contain the following:

<System PIN><Ringback number>*

The ringback number is optional.

Examples:

4711 or *4711*089123456*

If a ringback number is entered, it is dialled; otherwise the notification number is dialled.

You can now operate the answering machine via the keypad, as described in the previous sections.

Using the network mailbox

The network mailbox is your network provider's answering machine within the network. You cannot use the network mailbox unless you have **requested** it from your network provider.

Configuring fast access for the network mailbox

With fast access, you can dial the network mailbox or the integrated answering machine (Gigaset E495 only) directly.

Gigaset E490: Fast access is preset for the network mailbox. You only need to enter the number of the network mailbox.

Gigaset E495: The integrated answering machine is preset for fast access. You can configure the network mailbox instead.

Ask your network provider about this.

Configuring fast access for the network mailbox and entering the network mailbox number

 →  → Voice Mail → Set Key 1

Network Mailb.

Select and press **OK** ( = on).

 Enter the number for the network mailbox.



Save Press the display key.

 Press and **hold** (idle status).

The setting for fast access applies to all Gigaset E49H handsets.

Calling the network mailbox

 Press and **hold**. You are connected straight to the network mailbox.

 Press speaker key  if required. You will hear the network mailbox announcement.

Viewing the network mailbox message

When a message is recorded, you receive a call from the network mailbox. If you have requested Calling Line Identification, the network mailbox number will be displayed. If you take the call, the new messages are played back. If you do not take the call, the network mailbox number will be saved in the missed calls list and the message key flashes (→ page 28).

ECO DECT

You are helping to protect the environment with your Gigaset E490/E495.

Reduced energy consumption

Your telephone has a power-saving adapter plug and uses less power.

Reduced transmission power

The transmission power of your telephone is **automatically** reduced depending on the distance to the base station.


You can reduce the transmission power of the handset and base station even further by using Eco Mode or Eco Mode+:

- ◆ **Eco Mode**
80% transmission power reduction in standby and talk mode.
- ◆ **Eco Mode+**
100% transmission power deactivation during standby mode.




Eco Mode / Eco Mode+ can be activated/deactivated independently of each other and also work with multiple handsets.

Activate/deactivate Eco Mode / Eco Mode+ :


 →  Base → Add. Features
→ Eco Mode / Eco Mode+

OK Press the display key
 = activated).

Status displays

Display icon	
	Reception strength: – good to poor – no reception
	Eco Mode enabled
	Eco Mode+ enabled (displayed instead of the reception strength icon when in idle status)

Please note

- ◆ With **Eco Mode+** enabled, press and **hold** the talk key  to check that the base station can be reached. You will hear the ringing tone if the base station can be reached.
- ◆ When **Eco Mode+** is enabled:
 - call setup will be delayed by approx. 2 seconds.
 - handset standby time will be reduced by approx. 50%.
- ◆ Registering handsets that do not support **Eco Mode+** will cause the mode to be deactivated on the base station and all other handsets.
- ◆ Activating **Eco Mode** reduces the range of the base station.
- ◆ **Eco Mode / Eco Mode+** and repeater support (→ page 55) cancel each other out, i.e. you cannot use Eco Mode and Eco Mode+ when using a repeater.

Setting the alarm clock

Setting the alarm clock

Precondition: The date and time have already been set (→ page 13).

Activating/deactivating the alarm clock and setting the wake-up time



▶ Change multiple line input:

Activation

Select **On** or **Off**.

Time

Enter the wake-up time in 4-digit format.

Melody:

Select melody.

Volume:

Set the volume (1–6).

▶ Save the changes.

You will see the icon.

A wake-up call with selected ringer melody (→ page 53) is signalled on the handset. The wake-up call sounds for 60 seconds. is shown in the display. If no key is pressed, the wake-up call is repeated twice at five minute intervals and then turned off.

During a call, the wake-up call is only signalled by a short tone.

Deactivating the wake-up call/repeating after a pause (snooze mode)

Precondition: A wake-up call is sounding.

OFF

Press the display key. The wake-up call is deactivated.

or

Snooze

Press the display key or any key. The wake-up call is deactivated and then repeated after 5 minutes. After the second repetition the wake-up call is deactivated completely.

Using several handsets

Registering handsets

You can register up to six handsets to your base station.

Manual registration of Gigaset E49H to Gigaset E490/E495

You must activate manual registration of the handset on both the handset and the base station.

Once it has been registered, the handset returns to idle status. The handset's internal number is shown in the display e.g. INT 1. If not, repeat the procedure.

On the handset

→ → Handset → Register H/Set



Enter the system PIN of the base station (the default is 0000) and press **OK**. Base 1 flashes in the display.

On the base station

Within 60 seconds press and **hold** the registration/paging key on the base station (page 1) (approx. 3 seconds).

Registering other handsets

You can register other Gigaset handsets and handsets for other devices with GAP functionality as follows.

On the handset

▶ Start to register the handset as described in its user guide.

On the base station


Press and **hold** the registration/paging key on the base station (page 1) (approx. 3 sec.).

De-registering handsets

You can de-register any other registered handset from any registered Gigaset E49H handset.

 Open list of internal participants.

The handset you are currently using is indicated by .

 Select the internal participant you wish to deregister.

Options Open menu.

De-reg. H/Set No.

Select and press **OK**.

 Enter the current system PIN and press **OK**.

Yes Press the display key.


Locating a handset ("paging")

You can locate your handset using the base station.

▶ **Briefly** press the registration/paging key on the base station (page 1).

▶ All handsets will ring simultaneously ("paging"), even if the ringers are deactivated.


Ending paging

▶ **Briefly** press the registration/paging key on the base station or press the talk key  on the handset.

Making internal calls


Internal calls to other handsets registered to the same base station are free of charge.

Calling a specific handset

 Initiate internal call.

 Enter the number of the handset.

Or:

 Initiate internal call.

 Select handset.


 Press the talk key.

Calling all handsets ("group call")

 Initiate internal call.


 Press the star key. All handsets are called.

Ending a call

 Press the end call key.

Transferring a call to another handset

You can transfer an external call to another handset (connect).


 Open the list of handsets.

The external participant hears hold music if activated (→ page 55).

 Select a handset or Call All and press **OK**.

When the internal participant answers:

▶ If necessary announce the external call.

 Press the end call key.

The external call is transferred to the other handset.

If the internal participant does **not** answer or the line is busy, press the display key **End** to return to the external call.

When transferring a call you can also press the end call key  before the internal participant answers.

Then, if the internal participant does not answer or the line is busy, the call will automatically return to you (the display will show Recall).

Using several handsets

Internal consultation/conference calls

When you are conducting an **external** call, you can call an **internal** participant at the same time for consultation or hold a conference call between all 3 participants.

You are conducting an **external** call:



Open the list of handsets.
The external participant hears hold music if activated (→ page 55).



Select handset and press **OK**.
You are connected to the internal participant.

either:



Press the display key.
You are reconnected with the external participant.

Or:




Press the display key.
All 3 participants are connected with each other.

Ending a conference call



Press the end call key.

If an **internal** participant presses the end call key , the other handset remains connected to the external participant.

Accepting/rejecting call waiting

If you receive an **external** call during an **internal** call, you will hear the call waiting tone (short tone). With Calling Line Identification, the caller's number will appear in the display.

Ending an internal call, accepting an external call



Press the display key.

The internal call is **ended**. You are connected to the external caller.

Rejecting the external call

Reject Press the display key.

The call waiting tone is turned off. You remain connected with the internal participant. The ringer can still be heard on other registered handsets.

Listening in to an external call

Precondition: The Listening In function must be activated.

You are conducting an external call. An internal participant can listen in on this call and take part in the conversation. All the participants are made aware of the "listening in" by a signal tone.

Activating/deactivating listening in

 →  → Base →  Add. Features
→ Listening In

Press **OK** to activate/deactivate the function ( = on).



Press and **hold** (idle status).

Listening in

The line is engaged with an external call. Your screen will display information to that effect. You want to listen in to the external call.



Press and **hold** the talk key.


You can listen in to the call. All participants hear a signal tone. During this time, this handset displays the Conference message and it is not possible to dial another number from this handset.

Ending listening in



Press the end call key.

All participants hear a signal tone.

If the **first** internal participant presses the end call key , the handset that has "listening in" remains connected to the external participant.

Changing the name of a handset

The names "INT 1", "INT 2" etc. are assigned automatically on registration.

You can change these names. The name must be no more than 10 characters. The changed name is displayed in every handset's list.



Open the list of handsets. Your own handset is indicated by <.



Select handset.



Press the display key.



Enter name.



Press the display key.

Changing a handset's internal number

A handset is **automatically** assigned the lowest free number when it is registered. If all slots are occupied, number 6 is overwritten if this handset is in idle status. You can change the internal number of all registered handsets (1–6).



Open the list of handsets. Your own handset is indicated by <.



Open menu.

Edit H/Set No.

Select and press **OK**. The list of handsets is displayed.



The current number flashes.

Select a handset.



Enter the new internal number (1–6). The handset's old number is overwritten.



Press the display key to save the input.



Press and **hold** (idle status).

You will hear the error tone (descending tone sequence) if you assign an internal number twice.

- ▶ Repeat the procedure with a free number.

Using a handset as a room monitor

If the room monitor is activated, a previously saved destination number is called as soon as a set noise level is reached. You can save an internal or external number in your handset as the destination number.

The room monitor call to an external number stops after around 90 seconds.

The room monitor call to an internal number (handset) stops after approx. 3 minutes (depending on the base station).

When the room monitor is activated, all keys are locked except the end call key. The handset's speaker is muted.

When the room monitor is activated, incoming calls to the handset are indicated **without a ringer** and are only shown on the screen. The display and keypad are not illuminated and advisory tones are also turned off.

If you accept an incoming call, the room monitor is suspended for the duration of the call, but the function **remains** activated.

If you deactivate then reactivate the handset, the room monitor remains activated.

Warning

- ◆ You should always check the operation of the room monitor before use. For example, test its sensitivity. Check the connection if you are diverting the room monitor to an outside number.
- ◆ When the function is switched on, the handset's operating time is considerably reduced. If necessary, place the handset in the charging cradle. This ensures that the batteries do not run down.
- ◆ Ideally the handset should be positioned 1 to 2 metres away from the baby. The microphone must be directed towards the baby.
- ◆ The connection to which the room monitor is diverted must not be blocked by an activated answering machine.

Activating the room monitor and entering the destination number

 →  → Room Monitor

- ▶ Change multiple line input:

Room M.

Select On to activate.

Call to

Press the display key **Edit** and enter destination number.

External number: Select number from the directory or enter directly. Only the last 4 digits are displayed.

Internal number: **INT** →  (select handset or Call All if all registered handsets are to be called) → **OK**.

Store number with **Save**.


Level

Set noise level sensitivity (Low or High).

- ▶ Press **Save** to save the settings.

Changing a set external destination number

 →  → Room Monitor

 Scroll to the Call to line.

Edit Press the display key.

<C Delete existing number.

- ▶ Enter number as described in "Activating the room monitor and entering the destination number" (→ page 50).

- ▶ Press **Save** to save the settings.

Changing a set internal destination number

 →  → Room Monitor

 Scroll to the Call to line.

Delete Press the display key.

Edit Press the display key.

- ▶ Enter number as described in "Activating the room monitor and entering the destination number" (→ page 50).

- ▶ Press **Save** to save the settings.

Deactivating the room monitor remotely

Preconditions: The phone must support tone dialling and the room monitor should be set for an external destination number.

- ▶ Accept the call from the room monitor and press keys **9** **#**.

The room monitor function will deactivate after the call ends. There will be no further room monitor calls. The other room monitor settings (e.g. no ringer) on the handset will remain activated until you press the display key **OFF** on the handset.

To reactivate the room function with the same phone number:

- ▶ Turn on the activation again and save with **Save** (→ page 50).

Handset settings

Your handset is preconfigured, but you can change the settings to suit your individual requirements.

Quick access to functions

The display keys have a function preset by default. You can change the assignment.

To start the function, you then simply need to press the button.

Changing display key assignments

- ▶ Press and **hold** the left or right side of the display key.

The list of possible key assignments is opened. The following can be selected:

INT

Internal calls (→ page 47).

SMS

Assign menu for SMS functions to a key (→ page 31).

SMS Notific.

Assign menu for activating SMS notification to a key (→ page 34).

Withhold No.

Suppress Calling Line Identification for the next call (→ page 24).

If a function or number has already been assigned to the left display key, the selected function (or its abbreviation) will be displayed in the lowest display line above the display key.

Starting a function

With the handset in idle status, press the display key **briefly**.

The function menu is opened.

Changing the display language

You can view the display texts in different languages.

 →  → Handset → Language

The current language is indicated by .

 Select a language and press **OK**.

 Press and **hold** (idle status).

If you accidentally choose a language you do not understand:

Press keys in sequence.

 Select the correct language and press **OK**.

Setting the display

You have a choice of four colour schemes and several different contrasts.

 →  → Display

Colour Scheme

Select and press **OK**.



Select a colour scheme and press **OK** ( = current colour).



Press **briefly**.

Contrast Select and press **OK**.



Select contrast.

Save 

Press the display key.



Press and **hold** (idle status).

Setting the screen picture

You can display a screen picture (picture or digital clock) when the handset is in idle status. This will replace the idle status display. It may conceal the date, time and name.

The screen picture is not displayed in certain situations, e.g. during a call or when the handset has been de-registered.

If a screen picture has been activated, the menu item Screen Picture is marked with .

 →  → Display → Screen Picture

The current setting is displayed.

▶ Change multiple line input:


Activation

Select On (screen picture is displayed) or Off (no screen picture).

Selection:


Change screen picture if necessary (see below).

▶ Save the changes.

If the screen picture conceals the display, briefly press  to show the idle display with time and date.

Changing the screen picture

 →  → Display → Screen Picture

 Scroll to the Selection line.

View Press the display key. The active screen picture is displayed.

 Select screen picture and press **Save**.

▶ Save the changes.

Setting the display lighting

Depending on whether or not the handset is in the charging cradle, you can activate or deactivate the lighting. If it is activated, the display is permanently dimmed.

 →  → Display → Backlight

The current setting is displayed.

▶ Change multiple line input:

In Charger

Select On or Off.

Without Charger

Select On or Off.

Please note

With the On setting, the standby time of the handset can be significantly reduced.

Save Press the display key.

 Press and hold (idle status).

Activating/deactivating auto answer

If you activate this function, when you receive a call you can simply lift the handset out of the charging cradle without having to press the talk key .

 →  → Handset

Auto Answer


Select and press **OK** ( = on).

 Press and hold (idle status).


Changing the speaker/earpiece volume

You can set the loudspeaker volume for speaker mode to five different levels and the earpiece volume to three different levels.

 → Handset Volume

 Set the earpiece volume.

 Scroll to the Speaker line.

 Set the speaker volume.

Save Press display key if necessary to save the setting permanently.

Setting the volume during a call:

-  Press the control key.
-  Select volume.

Save Press display key if necessary to save the setting permanently.

The setting will automatically be saved after approx. 3 seconds, if not then press the display key **Save**.

If  is assigned to another function, e.g. call swap (→ page 25):



Options Open menu.

Volume Select and press **OK**.

Configure setting (see above).

Please note You can also make these settings via the menu (→ page 21).

Changing ringers

- ◆ **Volume:** You can choose between five volumes (1–5; e.g. volume 2 = ) and the "crescendo" ring (6; volume increases with each ring = .

- ◆ **Ringers:** You can select various ringers.

You can set different ringers for the following functions:


- ◆ **Ext. Calls:** for external calls
- ◆ **Internal Calls:** for internal calls
- ◆ **All:** the same ringer for all functions


Settings for individual functions

Set the volume and melody depending on the type of signalling required.

 → **Ringer Settings**

 Select setting, e.g. Ext. Calls and press **OK**.

 Set volume (1–6).

 Scroll to the next line.

 Select melody.

Save Press the display key to save the setting.

Same ringer for all functions

 → **Ringer Settings** → **All**

▶ Set volume and ringer (see "Settings for individual functions").

Save Press the display key and confirm the security prompt with **Yes** to save the setting.

 Press and **hold** (idle status).

Please note You can also make these settings via the menu (→ page 21).

Activating/deactivating the ringer

You can deactivate the ringer on your handset before you answer a call or when the handset is in idle status; the ringer can be deactivated permanently or just for the current call. The ringer cannot be re-activated while an external call is in progress.

Deactivating the ringer permanently

 Press and **hold** the star key.

The  icon appears in the display.

Reactivating the ringer

 Press and **hold** the star key.

Deactivating the ringer for the current call

Silence Press the display key.

Activating/deactivating the alert tone

In place of the ringer you can activate an alert tone. When you get a call, you will hear a **short tone** ("Beep") instead of the ringer.

 Press and **hold** the star key

and **within 3 seconds**:

Beep Press the display key. A call will

now be signalled by **one** short alert tone. **All** appears in the display.

Base station settings

Silent alarm

Incoming calls and other messages are indicated by a silent alarm.

In idle status:

 → Silent Alert


Press **OK** to activate or deactivate ( = on).

Please note

You can also make these settings via the menu (→ page 21).

Activating/deactivating advisory tones

Your handset uses advisory tones to tell you about different activities and statuses. The following advisory tones can be activated/deactivated independently of each other:

- ◆ **Key tones:** every key press is confirmed.
- ◆ **Acknowledge tones:**
 - **Confirmation tone** (ascending tone sequence): at the end of an entry/setting and when an SMS or a new entry arrives in the answering machine list or calls list
 - **Error tone** (descending tone sequence): when you make an incorrect entry
 - **Menu end tone:** when scrolling to the end of a menu
- ◆ **Battery tone:** the batteries need to be charged.
 - ▶  → Advisory Tones
 - ▶ Change multiple line input:
 - Key Tones
 - Select On or Off.
 - Confirm.
 - Select On or Off.
 - Battery

Select On, Off or In Call. The battery warning tone is only activated/deactivated and only sounds during a call.

- ▶ Save the changes.

You cannot deactivate the confirmation tone for placing the handset in the charging cradle.

Please note

You can also make these settings via the menu (→ page 21).

Restoring the handset default settings

You can reset individual settings and changes that you have made. This will not affect entries in the directory, call-by-call list, calls list, SMS lists or the handset's registration to the base station.



→  → Handset → Reset Handset

Yes

Press the display key.



Press and **hold** (idle status).

Base station settings

The base station settings are carried out using a registered Gigaset E49H handset.

Protecting against unauthorised access

Protect the system settings of the base station with a PIN known only to yourself. The system PIN must be entered when, for example, registering/deregistering a handset to/from the base station or when restoring the default settings.

Changing the system PIN

You can change the 4-digit system PIN set on the base station (default setting: 0000) to a 4-digit PIN known only by you. Gigaset E495: Setting a system PIN facilitates remote operation of the answering machine (page 43).

-  →  → Base → System PIN
-  →  → Base → System PIN and press **OK**.
-  Enter new system PIN. For security reasons, the PIN is shown as four stars (****).
-  Jump to the next line, re-enter new system PIN and press **OK**.
-  Press and hold (idle status).

Resetting the system PIN



If you have forgotten your system PIN you can reset the base station to the original code **0000**:

Disconnect the power cord from the base station. Hold down the registration/page-ing key on the base station while reconnecting the power cable to the base station. Release the key after a while.

The base station has now been reset and the system PIN **0000** set.

Please note — All handsets are deregistered and must be re-registered.


Activating/deactivating music on hold

-  →  → Base → Music on hold
- Press **OK** to activate or deactivate music on hold ( = on).

Repeater support

With a repeater you can increase the range and reception strength of your base station. You will need to activate repeater mode. This will terminate any calls that are in progress at the time.

Precondition: A repeater is registered. The **Eco Mode / Eco Mode+** is deactivated.

-  →  → Base → Add. Features → Repeater Mode
- Yes** Press the display key.


When repeater mode is active, the menu item is marked with .

Please note — Repeater support and **Eco Mode/Eco Mode+** (→ page 45) cancel each other out, i.e. both functions cannot be used at the same time.

Restoring the base station to the factory settings

When the settings are restored:

- ◆ handsets are still registered
- ◆ the system PIN is not reset

-  →  → Base → Base Reset
-  Enter the system PIN and press **OK**.
- Yes** Press the display key.

- Cancel the restoring process by pressing  or the display key **No**.
-  Press and hold (idle status)


Connecting the base station to the PABX

Connecting the base station to the PABX

The following settings are only necessary when your PABX requires them; see the PABX user guide.

You cannot send or receive SMS messages on PABXs that do not support Calling Line Identification.

Dialling modes and recall

The current setting is indicated by .

Changing the dialling mode

The following dialling modes can be selected:

- ◆ Tone dialling (DTMF)
 - ◆ Dial pulsing (DP)
-  →  → Base → Add. Features → Dialling Mode
-  Select dialling mode ( = on) and press **OK**.
-  Press and **hold** (idle status).

Setting recall

Your phone is preset at the factory for operation on the main connection. For operation on a PABX, you may have to change this value. Please refer to the user guide for your PABX.

 →  → Base → Add. Features → Recall

Select recall and press **OK** ( = set value). Possible values are:

80 ms, 100 ms, 120 ms,
180 ms, 250 ms, 300 ms,
600 ms, 800 ms.



Press and **hold** (idle status).

Saving an access code (outside line code)

Precondition: You may have to enter an access code for external calls in your PABX, e.g. "0".

 →  → Base → Add. Features → Access Code

 Enter or change access code, max. 3 digits.

▶ Save the changes.

If an access code has been saved:

- ◆ The access code is prefixed automatically when you select from the following lists: numbers of the SMS centres, calls list or answering machine list.
- ◆ The access code must be entered when dialling manually and when manually entering directory, emergency/shortcut numbers and SMS centre numbers.
- ◆ If you copy the recipient's number from the directory when sending an SMS, you have to delete the access code.
- ◆ An existing access code is deleted using **<<C**.

Setting pauses


Changing pause after line seizure

You can change the length of pause that is inserted between pressing the talk key and sending the number.

 Open menu.

Press keys.

 Enter digit for the pause

length (**1** = 1 sec.; **2** = 3 sec.;
3 = 7 sec.) and press **OK**.

Switching temporarily to tone dialling (DTMF)

If your PABX still operates with dial pulsing (DP), but you need tone dialling for a connection (e.g. to listen to the network mailbox) you must switch to tone dialling for the call.

Precondition: You are conducting a call or have already dialled an external number.

 Press the star key.

After the call is ended, dial pulsing is automatically activated again.

Changing the pause after the recall key

You can change the length of the pause if your PABX requires this (refer to the user guide for your PABX).

 Open menu.

Press keys.

 Enter a digit for the length of

the pause (**1** = 800 ms;
2 = 1600 ms; **3** = 3200 ms)
and press **OK**.

Changing a dialling pause (pause after access code)

Precondition: You have saved an access code (➔ page 56).

 Open menu.

Press keys.

 Enter a digit for the length of

the pause (**1** = 1 sec.;
2 = 2 sec.; **3** = 3 sec.;
4 = 6 sec.) and press **OK**.

To insert a dialling pause: press  for 2 seconds. A **P** appears in the display.

Service (Customer Care)

We offer you support that is fast and tailored to your specific needs!

Our Online Support on the Internet can be reached any time from anywhere.

www.gigaset.com/customercare

It provides you with 24/7 support for all our products. It also provides a list of FAQs and answers plus user guides and current software updates (if available for the product) for you to download.

You will also find frequently asked questions and answers in the appendix of this user guide.

For personal advice on our range of products and assistance with repairs or guarantee/warranty claims you can contact us on:

UK helpdesk: 0 84 53 67 08 12.


Please have your proof of purchase ready when calling with regard to guarantee/warranty claims.

Replacement or repair services are not offered in countries where our product is not sold by authorised dealers.

Questions and answers

If you have any questions about the use of your phone, you can contact us 24/7 at www.gigaset.com/customercare.

The table below contains a list of common problems and possible solutions.

<p>The display is blank.</p> <ol style="list-style-type: none"> 1. The handset is not switched on. <ul style="list-style-type: none"> ▶ Press and hold the end call key . 2. The batteries are flat. <ul style="list-style-type: none"> ▶ Charge or replace the batteries (→ page 10). <p>"Base x" flashes on the display.</p> <ol style="list-style-type: none"> 1. The handset is outside the range of the base station. <ul style="list-style-type: none"> ▶ Move the handset closer to the base station. <p>The base station's range is reduced because eco mode is activated.</p> <ul style="list-style-type: none"> ▶ Deactivate eco mode (→ page 45) or reduce the distance between the handset and the base station. 2. The base station is not turned on. <ul style="list-style-type: none"> ▶ Check the base station's mains adapter (→ page 8). <p>"Please register" flashes in the display.</p> <p>Handset has not been registered with the base station or has been deregistered.</p> <ul style="list-style-type: none"> ▶ Register the handset (→ page 46). <p>Handset does not ring.</p> <ol style="list-style-type: none"> 1. The ringer is deactivated. <ul style="list-style-type: none"> ▶ Activate the ringer (→ page 53). 2. Call divert set to All Calls. <ul style="list-style-type: none"> ▶ Deactivate call divert (→ page 25). <p>You cannot hear a ringer/dialling tone from the fixed line network.</p> <p>The phone cord supplied has not been used or has been replaced by a new cord with the wrong pin connections.</p> <ul style="list-style-type: none"> ▶ Please always use the phone cord supplied or ensure that the pin connections are correct when purchasing from a retailer (→ page 8). <p>Error tone sounds after system PIN prompt</p> <p>You have entered the wrong system PIN.</p> <ul style="list-style-type: none"> ▶ Reset the system PIN to 0000 (→ page 55). <p>Forgotten the system PIN.</p> <ul style="list-style-type: none"> ▶ Reset the system PIN to 0000 (→ page 55).

Call charges are not displayed.

1. Your network provider does not support this feature.
2. There are no metering pulses.
 - ▶ Ask your network provider to transmit the metering pulses.

The other party cannot hear you.

- You have pressed the  (INT) key. The handset is "muted".
- ▶ Activate the microphone again (→ page 23).

The number of the caller is not displayed despite CLIP.

- Calling Line Identification is not enabled.
- ▶ **The caller** should ask the network provider to enable Calling Line Identification (CLI).

You hear an error tone when keying an input (a descending tone sequence).

- Action has failed/invalid input.
- ▶ Repeat the operation.
 - ▶ Watch the display and refer to the user guide if necessary.

You cannot listen to messages on the network mailbox.

- ▶ Your PABX is set for dial pulsing.
- ▶ Set your PABX to tone dialling.

E495 Gigaset only:

No time is specified for a message in the calls list.

- Date and time have not been set.
- ▶ Set the date/time (→ page 13).

The answering machine announces "PIN is incorrect" during remote operation.

1. You have entered the wrong system PIN.
 - ▶ Enter the system PIN again.
2. The system PIN is still set to 0000.
 - ▶ Change the system PIN (→ page 55).

The answering machine is not recording any messages/has switched over to announce only.

- Its memory is full.
- ▶ Delete old messages.
 - ▶ Play back new messages and delete.

Authorisation

This device is intended for analogue phone lines in the UK.

Country-specific requirements have been taken into consideration.

We, Gigaset Communications GmbH, declare that this device meets the essential requirements and other relevant regulations laid down in Directive 1999/5/EC.

A copy of the 1999/5/EC Declaration of Conformity is available at this Internet address:
www.gigaset.com/docs.



Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a manufacturer's Guarantee under the conditions set out below:

- ◆ In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 24 months of purchase, Gigaset Communications shall, at its own option and free of charge, either replace the device with another device reflecting the current state of the art, or repair the said device. In respect of parts subject to wear and tear (including but not limited to, batteries, keypads, casing), this warranty shall be valid for six months from the date of purchase.

- ◆ This Guarantee shall be invalid if the device defect is attributable to improper treatment and/or failure to comply with information contained in the user guides.

Environment

- ◆ This Guarantee shall not apply to or extend to services performed by the authorised dealer or the customer themselves (e. g. installation, configuration, software downloads). User guides and any software supplied on a separate data medium shall be excluded from the Guarantee.
 - ◆ The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the Guarantee. Claims under the Guarantee must be submitted within two months of the Guarantee default becoming evident.
 - ◆ Ownership of devices or components replaced by and returned to Gigaset Communications shall vest in Gigaset Communications.
 - ◆ This Guarantee shall apply to new devices purchased in the European Union. For Products sold in the United Kingdom the Guarantee is issued by: Gigaset Communications GmbH, Schla-venhorst 66, D-46395 Bocholt, Germany.
 - ◆ Any other claims resulting out of or in connection with the device shall be excluded from this Guarantee. Nothing in this Guarantee shall attempt to limit or exclude a Customer's Statutory Rights, nor the manufacturer's liability for death or personal injury resulting from its negligence.
 - ◆ The duration of the Guarantee shall not be extended by services rendered under the terms of the Guarantee.
 - ◆ Insofar as no Guarantee default exists, Gigaset Communications reserves the right to charge the customer for replacement or repair.
 - ◆ The above provisions does not imply a change in the burden of proof to the detriment of the customer.
- To invoke this Guarantee, please contact the Gigaset Communications telephone service. The relevant number is to be found in the accompanying user guide.

Environment

Our environmental mission statement

Gigaset Communications GmbH assumes social responsibility and is actively committed to a better world. Our ideas, technologies and actions serve people, society and the environment. The aim of our global activity is to secure sustainable life resources for humanity. We are committed to a responsibility for our products that comprises their entire life cycle. The environmental impact of products, including their manufacture, procurement, distribution, use, service and disposal, are already evaluated during product and process design.

Further information on environmentally friendly products and processes is available on the Internet at www.gigaset.com.

Environmental management system



Gigaset Communications GmbH is certified pursuant to the international standards EN 14001 and ISO 9001.

ISO 14001 (Environment): certified since September 2007 by TÜV SÜD Management Service GmbH.

ISO 9001 (Quality): certified since 1/7/02/1994 by TÜV Süd Management Service GmbH.


Ecological energy consumption

The use of ECO DECT (→ page 45) saves energy and makes an active contribution towards protecting the environment.

Disposal

Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, details of which can be obtained from your local authority or the dealer you purchased the product from.

All electrical and electronic equipment must be disposed of separately from general household waste using the sites designated by local authorities.



If a product displays this symbol of a crossed-out rubbish bin, the product is subject to European Directive 2002/96/EC.

The appropriate disposal and separate collection of used equipment serve to prevent potential harm to the environment and to health. They are a precondition for the re-use and recycling of used electrical and electronic equipment.

For further information on disposing of your used equipment, please contact your local authority, your refuse collection service or the dealer you purchased the product from.

Appendix

Care

▶ Wipe the base station, charging cradle and the handset with a **damp** cloth (do not use solvent) or an antistatic cloth.

Never use a dry cloth as this can cause static discharge.

Contact with liquid

If the handset should come into contact with liquid:

1. **Switch the handset off and remove the batteries immediately.**
2. Allow the liquid to drain from the handset.
3. Pat all parts dry, then place the handset with the battery compartment open and the keypad facing down in a dry, warm place **for at least 72 hours** (not in a microwave, oven etc.).
4. **Do not switch on the handset again until it is completely dry.**

When it has fully dried out, you will normally be able to use it again.

In rare cases, contact with chemical substances can cause changes to the telephone's exterior. Due to the wide variety of chemical products available on the market, it was not possible to test all substances.

Specifications

Recommended batteries

Technology:

Nickel-metal-hydride (NiMH)

Size: AAA (Micro, HR03)

Voltage: 1,2 V

Capacity: 600 - 1200 mAh

We recommend the following battery types, because these are the only ones that guarantee the specified operating times, full functionality and long service life:

- ◆ GP 700 mAh
- ◆ Yuasa Phone 700 mAh
- ◆ Yuasa AAA 800 mAh
- ◆ Peacebay 650 mAh

The device is supplied with two recommended batteries.

Handset operating times/charging times

The operating time of your Gigaset depends on the capacity and age of the batteries and the way they are used. (All times are maximum possible times and apply when the display lighting is switched off).

	Capacity (mAh) approx.			
	500	700	900	1100
Standby time (hours)	180	250	320	395
Talktime (hours)	9	12	16	19
Operating time for 1.5 hrs of calls per day (hours)	80	115	150	180
Charging time (hours)	5	7	9	11

Due to the constant progression in battery development, the list of recommended batteries in the FAQ section of the Gigaset Customer Care pages is regularly updated:

www.gigaset.com/customercare

Base station power consumption

In standby mode:

Gigaset E490: approx. 0,8 watt

Gigaset E495: approx. 1,3 watt

During the conversation:


Gigaset E490: approx. 1,0 watt

Gigaset E495: approx. 1,5 watt

General specifications






DECT standard	is supported
GAP standard	is supported
No. of channels	60 duplex channels
Radio frequency range	1880–1900 MHz
Duplex method	Time multiplex, 10 ms frame length
Channel grid	1728 KHz
Bit rate	1152 kbit/s
Modulation	GFSK
Language code	32 kbit/s
Transmission power	10 mW, average power per channel
Range	up to 300 m outdoors, up to 50 m indoors
Base station power supply	230 V ~/50 Hz
Environmental conditions in operation	+5°C to +45°C; 20% to 75% relative humidity
Dialling mode	DTMF (tone dialling)/ DP (dial pulsing)

Pin connections on the telephone jack



Writing and editing text

The following rules apply when writing text:

- ◆ Control the cursor with    .
- ◆ Characters are inserted at the cursor position.
- ◆ Press the star key  to show the table of special characters. Select the required character, press the display key **Insert** to insert the character at the cursor position.
- ◆ The first letter of the name of directory entries is automatically capitalised, followed by lower case letters.

Writing an SMS/names

Press the relevant key several times to enter letters/characters.



Standard characters

	1x		2x		3x		4x		5x		6x		7x		8x		9x		10x
	1)		2)	1															
	a		b		c		ä		á		à		â		ã				ç
	d		e		f		ë		é		è		ê						
	g		h		i		4		ï		í		ì		î				
	j		k		l		5												
	m		n		o		ö		ñ		ó		ò		ô				õ
	p		q		r		s		7		β								
	t		u		v		8		ü		ú		ù		û				
	w		x		y		z		9		ÿ		ý		æ		ø		å
	.		,		?		i		0										

- 1) Space
- 2) Line break

When you press and **hold** a key, the characters of that key appear in the display and are highlighted one after the other. When you release the key, the highlighted character is inserted into the input field.

Setting upper/lower case or digits

Press the hash key  **briefly** to switch from "Abc" mode to "123" and from "123" to "abc" and from "abc" to "Abc" (upper case: 1st letter upper case, all others lower case). Press the hash key  **before** entering the letter.

You can see briefly in the display whether upper case, lower case or digits is selected.

Accessories

Gigaset handsets

Upgrade your Gigaset to a cordless PABX:

Gigaset E49H handset

- ◆ Dust and splashproof casing
- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Silent alarm
- ◆ Polyphonic ringers
- ◆ Directory for around 150 entries
- ◆ SMS (precondition: CLIP must be enabled)
- ◆ Headset socket
- ◆ Room monitor

www.gigaset.com/gigasete49h



Gigaset SL 78H handset

- ◆ Illuminated graphic colour display (256k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringers
- ◆ Directory for around 500 entries
- ◆ SMS (precondition: CLIP must be enabled)
- ◆ PC interface to manage directory entries
- ◆ Bluetooth
- ◆ Room monitor

www.gigaset.com/gigaset-sl78h



Gigaset C47H handset

- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringers
- ◆ Directory for around 150 entries
- ◆ SMS (precondition: CLIP must be enabled)
- ◆ Headset socket
- ◆ Room monitor

www.gigaset.com/gigasetc47h



Gigaset S68H handset

- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringers
- ◆ Directory for around 250 entries
- ◆ Picture CLIP
- ◆ SMS (precondition: CLIP must be enabled)
- ◆ Headset socket
- ◆ Room monitor

www.gigaset.com/gigaset68h



Gigaset SL37H handset


- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringers
- ◆ Directory for around 250 entries
- ◆ Picture CLIP
- ◆ SMS (precondition: CLIP must be enabled)
- ◆ PC interface e.g. for managing directory entries, ringers and screensavers
- ◆ Headset socket
- ◆ Bluetooth
- ◆ Room monitor
- ◆ Walky-talky function

www.gigaset.com/gigasetsl37h




Mounting the base station to the wall


Mounting the base station to the wall



approx. 2.5 mm



Mounting the charging cradle to the wall



approx. 2.5 mm



Index

B

- Base station
 - connecting 8
 - connecting to PABX 56
 - restoring factory settings 55
 - setting 54
 - setting up 8
 - system PIN 55
- Battery
 - charging 1, 12
 - display 1
 - icon 1
 - inserting 10
 - recommended batteries 62
 - tone 54

C

- Call
 - accepting 22
 - diverting (connecting) 47
 - ending 22
 - external 22
 - internal 47
 - make anonymous call 24
 - participant listening in 48
 - picking up from ans. machine 41
 - transferring (connecting) 49
 - two-way record 41
- Call divert 25
- Call duration 22
- Call screening during recording 41
- Call swap 25
- Call waiting
 - accepting/rejecting 24
 - activating/deactivating 24
 - external call 24
 - internal call 48
- Call-by-call
 - key 1
 - list 26
 - numbers 26, 30
- Calling
 - anonymously 24
 - external 22
 - internal 47
- Calling Line Identification 22
- cancel once 24
- Calls list 29

A

- Access code 56
 - for a PABX 56
- Access protection 54
- Accessories 64
- Acknowledge tones 54
- Activating
 - advisory tones 54
 - answering machine 38
 - answering machine
 - (remote operation) 43
 - handset 18
 - keypad lock 18
 - listening in 48
 - muting ringer 36
 - ring delay 52
 - room monitor 50
 - two-way record 41
- Advisory tones 54
- Alarm clock 46
- Alert tone 53
- Announcement
 - (answering machine) 39
- Announcement mode
 - (answering machine) 38, 39
- Anonymous calling 24
- Answering machine 38
 - activating/deactivating 38
 - deleting messages 40
 - list 28, 29
 - playing back messages 40
 - recording announcement/announce
 - only 38
 - remote operation 43
 - scrolling back 40
 - scrolling forward 40
- Answering machine, see also
 - Network mailbox
- Assigning numerical keys 51
- Authorisation 59
- Automatic
 - call acceptance 22, 52
 - network provider preselection 30
 - ring delay 52

- Canceling preselection 30
 - Care of the telephone 61
 - CD, see Call divert
 - Changing
 - destination number 50
 - dialling mode 56
 - display language 51
 - earpiece volume 52
 - internal number of a handset 49
 - name of a handset 49
 - pause time 57
 - ringer 53
 - speaker volume 52
 - system PIN 55
 - Character set 32, 33
 - Charge status display 1
 - CLI, CLIP 22
 - CLIP picture 23
 - CLIR 24
 - Conference (internal) 48
 - Confirmation tone 54
 - Connecting the headset 14
 - Connecting, base station to PABX 56
 - Consultation call (internal) 48
 - Control key 1, 16
 - Correcting incorrect entries 17
 - Cost saving function
 - (remote operation) 42
 - Customer Care 58
- D**
- Deactivating
 - advisory tones 54
 - answering machine 38
 - handset 18
 - keypad lock 18
 - listening in 48
 - muting ringer 36
 - ring delay 52
 - room monitor 50
 - two-way record 41
 - Delete key 17
 - Deleting
 - announcement for answering
 - machine 39
 - characters 17
 - message 40
 - deregistering (handset) 47
 - destination number (room monitor) 50
 - dial pulsing 56
- Dialling**
- call-by-call list 27
 - directory 27
 - mode 56
 - using shortcut 27
 - Dialling pause 57
 - entering 1
 - Directory 26
 - copying number from text 28
 - managing entries 27
 - opening 16
 - order of entries 26
 - saving entry 26
 - saving the sender's number (SMS) 33
 - sending entry/list to handset 27
 - using to enter numbers 28
- Display**
- changing display language 51
 - contrast 51
 - in idle status 18
 - lighting 52
 - memory (directory/call-by-call) 27
 - network mailbox message 44
 - number (CLI/CLIP) 22
 - screen picture 52
 - setting 51
 - wrong language 51
- Display keys 1, 17**
- assigning 51
 - Disposal 61
 - DP (dial pulsing) 56
 - Draft message list (SMS) 31
- E**
- Earpiece mode 23
 - Earpiece volume 52
 - ECO DECT 45
 - Eco mode 45
 - Eco mode+ 45
 - End call key 1, 22
 - Ending, call 22
 - Ending, see Deactivate
 - Entry
 - saving, changing (preselection) 30
 - select from directory 26
 - Environment 60
 - Error tone 54
 - External call 25
 - call waiting 24
 - divert to ans. mach 41

- F**
Fast access
 answering machine 42
 network mailbox 44
- G**
Group call 47
Guarantee Certificate 59
- H**
Handset
 activating/deactivating 18
 advisory tones 54
 changing internal number 49
 changing name 49
 changing the number 49
 contact with liquid 61
 de-registering 46, 47
 display language 51
 display lighting 52
 diverting a call 47
 earpiece volume 52
 idle status 18
 list 16
 locating 47
 muting 23
 paging 47
 registering 46
 restoring to factory settings 54
 screen picture 52
 setting 51
 setting up 10
 speaker volume 52
 using room monitor 49
 using several 46
- Handset operating time
 in room monitor mode 50
- Hash key 1, 18
- Headset socket 14
- Hearing aids 6
- I**
Icon
 alarm clock 46
 answering machine 38
 for new messages 28
 keypad lock 18
 new message 40
 new SMS 32
 ringer 53
- Idle status (display) 18
Idle status, returning to 18
Incoming message list (SMS) 32
Incorrect input (correction) 17
Installing, base station 8
Internal
 conference 48
 consulting 48
 listening in 48
 making calls 47
Internal call 47
 call waiting 48
- K**
Key 1 (fast access) 1, 42
Keypad lock 18
Keys
 assigning directory entry 26
 call-by-call list 1
 control key 1, 16
 delete key 17
 display keys 1, 17
 end call key 1, 22
 fast access 1, 42
 hash key 1, 18
 message key 1
 on/off key 1
 recall key 1
 shortcut 26, 27
 speaker key 1, 14
 star key 1
 talk key 1, 22
- L**
Language, display 51
Last number redial 28
Linking, see SMS
Liquid 61
List
 answering machine 28, 29
 call-by-call list 26
 calls list 29
 handsets 16
 missed calls 29
 network mailbox 29
 SMS draft message list 31
 SMS incoming message list 32
 SMS list 29
 Listening in to a call 48
 Locating, handset 47

Index

- Lock
 - activating/deactivating keypad lock . 18
- M**
 - Mailbox ID, see SMS
 - Mailboxes, see SMS
 - Mains adapter 6
 - Making calls
 - accepting a call 22
 - cost-effective calls 30
 - external 22
 - internal 47
 - Manual last number redial 28
 - Medical appliances 6
 - Memory
 - directory/call-by-call 27
 - Menu
 - end tone 54
 - opening 16
 - overview 20
 - prompting 17
 - Message key
 - open list 32
 - opening lists 28
 - Messages
 - deleting 40
 - key 1
 - marking as "new" 40
 - new message icon 40
 - playing back 40
 - Microphone 1
 - Missed calls 29
 - Music on hold 23, 55
 - setting 55
- Muting
 - first ring 36
 - handset 23
- N**
 - Name
 - of a handset 49
 - Network mailbox 44
 - Network provider (numbers list) 26
 - Network provider preselection,
 - automatic 30
- Network services 24
- Notification by SMS 34
- Number
 - as destination for room monitor . . . 50
 - copying from an SMS text 33
 - copying from directory 28
 - copying to directory 28
 - displaying caller's number (CLIP) . . . 22
 - entering with directory 28
 - saving in the directory 26
- Numbers list
 - network provider 26
- O**
 - On/Off key 1
 - Order in directory 26
- P**
 - PABX
 - connecting base station 56
 - pauses 57
 - saving access code 56
 - setting dialling mode 56
 - setting recall 56
 - SMS 36
 - switching to tone dialling 57
 - Pack contents 7
 - Paging 47
 - Paging key 2
 - Pause 57
 - PIN change
 - system PIN 55
 - Pin connections 62
 - Playing back
 - announcement (answering machine) . . . 39
 - message (answering machine) 40
 - Power consumption 62
 - Preselection 30
 - cancelling 30
 - Protecting the phone against
 - access 54
- Q**
 - Questions and answers 58

- R**
- Recall 56
 - Recall key 1
 - pause after 57
 - Reception booster, see Repeater
 - Recording
 - quality 42
 - time 42
 - two-way record 41
 - Redirect, see Call divert
 - Registering (handset) 46
 - Registration key 2
 - Remote operation 43
 - Repeater 55
 - Ring delay 42, 52
 - Ringback 24
 - Ringer
 - changing 53
 - muting 36
 - setting volume 53
 - Room monitor 49
- S**
- Saving (access code) 56
 - Screen picture 52
 - Searching in directory 26
 - Sending directory entry to handset 27
 - Sensitivity (room monitor) 50
 - Service 58
 - Setting the date 13
 - Setting the time 13
 - Setting up
 - handset 10
 - Shortcut 20
 - Signal tone, see Advisory tones
 - Silent alarm 54
 - SMS 31
 - active send service centre 35
 - changing mailbox 35
 - deleting 32, 33
 - diverting 33
 - draft message list 31
 - incoming message list 32
 - linked 31
 - list 29
 - mailbox ID 34
 - mailboxes 34
 - notification by SMS 34
 - notification number 34
- notification type 34
 - PIN protection 34
 - reading 32, 33
 - receiving 32
 - replying to or diverting 33
 - saving number 33
 - self help with error messages 37
 - sending to a personal mailbox 35
 - troubleshooting 37
 - writing 31, 63
- SMS centre
 - changing number 35
 - setting 35
- SMS to PABXs 36
- Snooze mode 46
- Sound, see Ringer
- Speaker 23
 - key 1, 14
- Special functions 56
- Specifications 62
- Speed dial 26
- Star key 1
- System settings 54
- T**
- Talk key 1, 22
 - Telephone jack, pin connections 62
 - Text message, see SMS
 - Tone dialling 56, 57
 - Troubleshooting 58
 - SMS 37
- U**
- Unknown 23
 - Unknown caller 23
- V**
- Viewing the network mailbox
 - message 44
 - VIP (directory entry) 27
 - Volume
 - earpiece volume 52
 - handset speaker volume 52
 - ringer 53
 - setting 53
- W**
- Warning tone, see Advisory tones
 - Writing (SMS) 31
 - Writing, editing text 63

